

**ST501 Free-standard**

# RECORDING SOFTWARE *User's Manual*



rev. 1.6.1

## **Table of Contents**

Revision History .....	vi
<b>Getting Started .....</b>	<b>1</b>
Introducing ST7501 .....	1
Special Features .....	1
ST7501 Server and Client Components.....	2
Usage Scenario.....	2
ST7501 Server Functionality .....	3
ST7501 LiveClient Functionality .....	4
ST7501 Playback Functionality .....	5
Minimum System Requirements .....	6
<b>ST7501 Installation.....</b>	<b>7</b>
Installing the ST7501 Software .....	7
<b>ST7501 Server .....</b>	<b>10</b>
Activating the ST7501 Server.....	10
How to Configure the Server.....	10
How to Stop/Reboot the Server.....	10
<b>ST7501 LiveClient Configuration.....</b>	<b>12</b>
Activating the ST7501 LiveClient and Logging in to a ST7501 Server.....	12
ST7501 LiveClient User Interface .....	13
Menu Bar.....	13
Status Panel.....	13
Quick Access Bar .....	14
Live Video Monitoring Window .....	14
Device tree .....	15
Camera Control Panel.....	16
Pan/Tilt/Zoom (PTZ) Control Panel.....	16
Two Way Audio Control Panel.....	17
Language Selection .....	17
Event Window .....	18
Instant Playback.....	19
Audio Control .....	19
How to Manage Devices .....	20
Insert Devices .....	20
Enable SVC .....	24
Insert a Video Server.....	26
Update Devices.....	28
Delete Devices from the ST7501 Server.....	29
Batch Insert Devices .....	30

View Live Videos .....	34
Dual / Multiple Streams .....	34
Fisheye Display Modes .....	34
Refresh .....	38
Streaming Server .....	38
Camera Settings .....	39
Remove Live Video from the Video Monitoring Window .....	39
How to Change the ST7501 LiveClient Layout .....	40
Changing the Layout of the Live Video Monitoring Window .....	40
Switch Video Channels .....	40
Configure Layout Mode .....	40
Rotating Video Pages .....	41
Edit Layout .....	41
Maximize/Minimize the Live Video Monitoring Window .....	43
View Live Video on Dual Monitor .....	44
View up to 32 channels simultaneously .....	45
Using different layouts on each monitor .....	45
View Live Video with Multiple Monitors .....	46
How to Manage User Accounts .....	47
The Default User Roles and Permissions of User Accounts .....	47
Manage a User Account .....	48
Add a New User Account .....	48
Permission of the User Account .....	50
Delete the User Account .....	51
How to Set up Association Management .....	52
Association Management .....	52
How to Set up Event Management .....	54
Event Management .....	54
How to Configure the Station General Settings .....	60
Server Settings .....	60
Log Settings .....	60
How to Configure Station Network Settings .....	61
Port Settings .....	61
UPnP Settings .....	61
Proxy Settings .....	61
How to Edit Recording Groups .....	62
Recording Storage Settings .....	62
Default Storage Group Settings .....	63
Add New Recording Group(s) .....	65
How to Edit Recording Schedules .....	66

Edit Schedule List .....	67
Add Schedules .....	67
Rename Schedules .....	67
Delete Schedules .....	67
Load/Save Schedule Templates .....	68
Edit Camera List .....	69
Edit Time Frame List .....	70
Add New Time Frames .....	71
Recording Settings .....	72
The Concept of Repeat Frequency .....	73
Repeat Frequency: Daily Setting .....	74
Repeat Frequency: Weekly Setting (Day-based) .....	77
Repeat Frequency: Monthly Setting (Day-based) .....	80
Repeat Frequency: Yearly Setting (Day-based) .....	82
How to Manually Begin /Stop Recording .....	84
How to Edit Scheduled Backup Settings .....	85
Select Backup Source .....	85
Setup Backup Schedule .....	86
Select Backup Target .....	86
Other Options .....	86
How to Configure Station Server Settings .....	87
DDNS Settings .....	87
Network Storage Settings .....	88
SMTP Settings .....	89
Relay Settings .....	90
How to Use the Talk Panel .....	91
Add a Camera to the Talk Panel .....	91
Remove a Camera from the Talk Panel .....	93
How to Configure E-map Settings .....	94
Upload an E-map .....	94
User Interface of E-map Settings Page (View Mode) .....	95
Quick Access Bar .....	96
Status Panel .....	96
User Interface of E-map Settings Page (Edit Mode) .....	97
Device Management .....	98
Live View Dialog Settings .....	99
Open Live View Dialog .....	99
Send to Single View .....	99
E-map Link .....	100
How to Configure Client Settings .....	103



Snapshot Settings .....	103
Take a Snapshot .....	104
Recording Settings .....	105
Type 1: Record to EXE .....	105
Type 2: Record to 3GP .....	105
Type 3: Record to AVI .....	106
Built-in Media Player--EXE .....	109
View Settings .....	111
Display Location .....	111
Date and Time Format .....	112
Video Display Mode .....	112
Font Settings .....	112
General Settings .....	113
Event Settings .....	113
Rotation Settings .....	113
System Settings .....	113
Display Settings .....	114
Joystick Settings .....	115
Enable Joystick .....	115
Proxy Settings .....	119
How to Search for a Device on the Device Tree .....	120
How to Print a Video Image .....	121
How to Lock ST7501 LiveClient for Security Concerns .....	121
How to Log out from the ST7501 Server .....	122
How to Exit ST7501 LiveClient .....	122
<b>ST7501 Playback Configuration .....</b>	<b>123</b>
Activating ST7501 Playback and Logging in to a Server .....	123
ST7501 Playback User Interface .....	124
Menu Bar .....	124
Status Panel .....	124
Quick Access Bar .....	125
Recorded Video Playback Window .....	125
Language Selection .....	126
Query Panel-- Browsing Page .....	126
Query Panel--Time Search Page .....	127
Query Panel--Event Search Page .....	128
Query Panel--Log Viewer Page .....	129
Video Clips List Window .....	130
Playback Control Panel .....	131
How to Playback Recorded Video .....	132

Select a Recorded Video Clip .....	132
Remove Recorded Video Clips from Video Cells .....	134
Timeline Slider Bar and Histogram .....	134
Zoom in / out of the Histogram .....	135
Audio Control .....	136
How to Change the Playback Layout .....	137
Changing the Layout of the Recorded Video Playback Window .....	137
Switch Video Channels .....	137
Configure Layout Mode .....	137
Maximize/Minimize the Recorded Video Playback Window .....	138
View Recorded Video with Multiple Monitors .....	139
How to Backup Recorded Video .....	140
How to Search for a Video Clip in a Specific Period of time .....	146
How to Search for Events .....	147
Select Event Category .....	148
Event Category- All Events .....	148
Event Category- All Motion Events .....	148
Event Category- All IVA events .....	149
Event Category- All DI Events .....	149
Event Category- Named DI Events .....	150
Start Event Search .....	151
Backup the Event Videos .....	152
How to Search Logs .....	153
Select Log Category/Log Type/Log Level .....	154
Search All Local Logs .....	155
Search Login History .....	155
Search Login Activities .....	156
How to Configure Client Settings .....	158
Snapshot Settings .....	158
Export Settings .....	158
View Settings .....	160
Proxy Settings .....	160
General Settings .....	160
System Settings .....	160
Display Settings .....	160
How to Search for a Device on the Device Tree .....	160
How to Print a Video Image .....	160
How to Lock ST7501 Playback for Security Concerns .....	161
How to Log out from the ST7501 Server .....	161
How to Exit ST7501 Playback .....	161
Import and Export Utility .....	162
Export Utility .....	162
Import Utility .....	162
ST7501 Service Control Tool .....	163

## Revision History

### Rev. 1.5.2:

1. Supports Video Server VS8801 to be attached to ST configuration.
2. Supports automated saving of current layout settings.
3. Added Playback as one of the user's privileges.
4. Reflected the changes to the access to an individual camera management session from a mocked browser to the use of IE browser.

### Rev. 1.6.1:

1. Supports adaptive frame rate adjustment with the new SVC codec cameras.
2. Supports auto stream size functionality.
3. Added functionalities related to FE8171V fisheye camera.
4. Added description for fisheye-specific screen control and playback functions.
5. Replaced some description for the changes/improvements made on the user interface.

# Getting Started

## Introducing ST7501

VIVOTEK ST7501 is the new generation recording software, featuring reliable recording and easy system management for diverse IP surveillance applications. ST7501 has three major components including: ST7501 Server for recording, ST7501 LiveClient for viewing live media data and system management, and ST7501 Playback for browsing the database and retrieving the recorded media data. You can install and run the three components on a single computer, or install them on three separate computers.

ST7501 Server is able to record network video streams up to 32 channels, and ST7501 LiveClient allows for real-time remote monitoring. For video playback, you can use ST7501 Playback to retrieve the database with multiple advanced functions such as searching, browsing, and exporting. With ST7501 LiveClient and ST7501 Playback installed on other computers in different locations, you can have live viewing and database access for more efficient video management. Working seamlessly with VIVOTEK network cameras and video servers, ST7501 recording software provides you with a reliable and seamless video surveillance system.

## Special Features

- Convenient Remote Access via Client/Server Architecture
- Effective & Reliable Event Trigger Management
- Real-time 32-channel Live Viewing and Simultaneous 16-channel Playback
- Multiple Simultaneous Streams for Different Media Platforms
- Activity Adaptive Streaming for Dramatically Reducing Bandwidth and Storage Space
- Extremely Versatile Settings for Recording Storage and Recording Schedule Management
- Role-based User Management to Enhance Security Operations
- Efficient Data Backup, Search, and Export
- Intelligent PTZ/ E-PTZ Remote Camera Control
- Overall Device Management through Intuitive E-map Feature
- Instantly Playback Event Recording
- Built-in Instant Player for Playback
- Accessible through NAT Using the Public IP
- Supports Two Way Audio
- Supports Auto Stream Size
- Supports SVC-T adaptive frame rate setting

\* The ability to extend devices is also subject to the network bandwidth and computer performance.

## ST7501 Server and Client Components

ST7501 has three components: one server component--**ST7501 Server**, and two client components--**ST7501 LiveClient** and **ST7501 Playback**.


**ST7501 Server** provides a centralized management site for video recording. **ST7501 LiveClient** is a client program for the user to login to the target server over the network to modify the server's configuration, edit the server's recording storage, schedules and many other functions on the server; **ST7501 Playback** is another client program for the user to login and browse the recorded video database and video clips related to specific events on the server.

## Usage Scenario

The three components can be installed separately or combined together on the same host. You can just install the components you need on your local host. For example, you can only install ST7501 LiveClient on your local computer to monitor the live video from a remote ST7501 Server; or you can only install ST7501 Playback on another local computer to login to a remote server to review recorded videos.

For users that only manage a few cameras, we recommend installing the client and server components on the same computer. A host with all of the three components installed is recognized as a stand-alone site. All the functions can be simultaneously performed on one single site.

Shown below is the usage scenario of ST7501 Server and client components.




## ST7501 Server Functionality

- Serves as a remote video management site for all the logged in clients
- 32-channel video recording
- Store recorded data onto multiple hard/network disks
- Live video for the local/remote LiveClient users
- Recorded video for the local/remote Playback users
- Zero latency database recovery

To configure the server, you should use ST7501 LiveClient to log in. The convenient and intuitive user interface in ST7501 LiveClient will enable you to edit the settings of the target server.

## ST7501 LiveClient Functionality


- Server function control
  - User account management
  - Recording storage management
  - Recording schedule management
  - Recorded data backup
  - Event trigger management
- Flexible video live view layout
  - Dual screens for maximum 32 channels simultaneous monitoring
  - 1x1, 2x2, 1+5, 3x3, 1+12, 4x4, 5x5, 1+31 monitoring layouts
  - Multiple video viewing pages
- Convenient evidence and data export
- E-map for overall management
- Network storage for recording
- Convenient switching among multiple monitors
- PTZ / E-PTZ operation panel for camera control
- Support two way audio
- Instant playback for event recording
- Support joystick control
- Remote configuration for network cameras





## ST7501 Playback Functionality

- Browse the database of recorded video from the server
- Flexible video playback layout
  - Maximum 16 channels simultaneous playback
  - 1x1, 2x2, 1+5, 3x3, 1+12, 4x4 playback layouts
- Support powerful playback functions
  - 1/8x, 1/4x, 1/2x slow-down playback
  - 2x, 4x, 8x, 16x, 32x, 64x video playback speed
- Support convenient evidence and data exporting
  - Export media files of recorded video
  - Support Snapshot
  - Support Print out
- Support convenient switching among multiple monitors
- Search engine
  - Time search
  - Event search
  - Log search
- Playback while recording



## Minimum System Requirements

Before installing the ST7501 software, please make sure your system meets the following recommended minimum system requirements.

If you would like to install ST7501 Server only, please follow the requirements as below:

Server	
Operating System	Windows Server 2000, 2003, 2008 / Windows XP Professional (32 and 64 bit), Windows Vista Business (32 and 64 bit), Windows 7 (32 and 64 bit)
Channels	Below 32 channels
CPU	Intel Core 2 Duo E6400 2.13GHz or above
RAM	2 GB or above
Network Interface Card	Ethernet, 1 Gbit recommended
Graphics Adapter	AGP or PCI-Express, minimum 1024×768, 16 bit colors
Hard Disk Type	ATA-100, SATA, SCSI, SAS (7200 rpm or faster) in NTFS format
Hard Disk Space	750 GB free *

If you would like to install both the server and client programs, please follow the requirements as below:

Server, LiveClient, and Playback		
Operating System	Windows Server 2000, 2003, 2008 / Windows XP Professional (32 and 64 bit), Windows Vista Business (32 and 64 bit), Windows 7 (32 and 64 bit)	
Channels	Below 16 channels	16 ~ 32 channels
CPU	Core 2 Duo E6400 2.13GHz or above	Core 2 Duo E8600 3.33GHz or above
RAM	2 GB or above	
Network Interface Card	Ethernet, 1Gbit recommended	
Graphics Adapter	AGP or PCI-Express, minimum 1024×768, 16 bit colors Minimum 128MB Video RAM, 512MB recommended	
Hard Disk Type	ATA-100, SATA, SCSI, SAS (7200 rpm or faster) in NTFS format	
Hard Disk Space	750 GB free *	





- Only users with Administrator privileges can install or use ST7501 on a Windows Vista system.
  - The required hard disk space will depend on the amount of network cameras and recording group settings. Please add more hard disks if you want to expand the configuration.
- \* 32-CH, VGA, about 1 week recording: 750 GB  
 32-CH, 2-megapixel, about 1 week recording: 2TB x 2

# ST7501 Installation


## Installing the ST7501 Software

1. Run **ST7501\_Setup.exe** on your computer. Click **I Agree** the License Agreement and specify a location to install the program.




2. Select the items you want to install, then click **Next** to continue.

- If you want to install both ST7501 Server component and Client components, please follow the steps below to install the database.



Server component  
Client components

3. Assign a **username** and **password** for the ST7501 Server and click **Next** to continue.



Please record the username and password for login later.


4. Install a database on your server. There are two options--**PostgreSQL** (8.2 version or above) or **SQL server** (2005 express version or above). In order to avoid conflicts among different databases, we suggest you remove the original database from your host. Then follow the instructions below to install PostgreSQL or SQL server.

## PostgreSQL


**Please note that PostgreSQL may interrupt an antivirus program.**

Follow the steps below to install PostgreSQL Server:


- a. Select PostgreSQL from the drop-down list and assign a password. ST7501 server will by default store the recorded media file under c:\Recording. Click **Browse** ... to change the path if you plan to store the data under another path. Then click **Next** to continue.



- b. If you do not have PostgreSQL, select the first option to begin the installation. If you already have PostgreSQL installed on your host, select the second option to enter the related information.



- c. Wait for the installation process to complete, then click **Close** to exit the installation program.



## SQL Server

Follow the steps below to install SQL Server:

- a. Select SQL Server from the drop-down list and assign a password. ST7501 server will by default store the recorded media file under c:\Recording. Click **Browse** ... to change the path if you plan to store the data under another path. Then click **Next** to continue.

- b. If you do not have SQL server, select the first option to begin the installation. If you already have SQL server installed on your host, select Windows authentication or SQL Server authentication. (Username and Password may be necessary according to the settings when you install the SQL server.) Click **Install** to begin the installation.

- c. Wait for the installation process to complete, then click **Close** to exit the installation program.



Once you have created a user account for a ST7501 station, you can login to a ST7501 Server from any computer over the network through LiveClient and Playback utilities.

# ST7501 Server

## Activating the ST7501 Server

ST7501 Server is a service program that will run automatically when the computer starts up.

## How to Configure the Server


Please follow the steps below to configure the ST7501 Server:

1. Find a local/remote computer that has an ST7501 LiveClient installed.
2. Activate ST7501 LiveClient and login to the target ST7501 Server.
3. Configure the server using the ST7501 LiveClient user interface.


## How to Stop/Reboot the Server

Please follow the steps below to stop/reboot the server:

1. Under Microsoft Windows, choose "**Start > Settings > Control Panel > Administrative Tools > Services.**" You may also right-click on the My Computer icon to find the Manage command to enter the Computer Management window.
2. The **Service** window will pop up. Search for "**ST7501 Uranus Watch Dog**" from the list.



3. Right-click **ST7501 Uranus Watch Dog** and click **Stop** to stop the services of ST7501 Server.



4. Click **Restart** to reset ST7501 Server.




# ST7501 LiveClient Configuration

## Activating the ST7501 LiveClient and Logging in to a ST7501 Server

ST7501 LiveClient allows you to monitor live video from cameras managed by the ST7501 Server; it is also the main user interface to control many of the server functions.

After installing the ST7501 LiveClient program, please follow the steps below to activate ST7501 LiveClient:


1. Run the **ST7501 LiveClient** program.
2. A **Login** window will pop up. Enter the information as shown below:
  - If you want to login to a remote ST7501 Server, enter the **IP Address**, **User Name**, **Password** and the **Communication Port** of the target server correctly. Click **Login** to log in to the target server.
  - If you want to login to a local host that is running ST7501 Server, check the **Login local station** checkbox, then the local **IP Address** will be displayed automatically. Enter the **User Name**, **Password**, and **Communication Port** of the local server for login. Click **Login** to login to the target server.



3. The ST7501 LiveClient monitoring window will be displayed.




- If your network environment need to set up proxy, click **More >>** to extend the login window, then click **Proxy Settings** to open the dialog. Then enter related information to link to your proxy server.



- Available functions of the ST7501 LiveClient program will be enabled according to the role of your login account. For more details about the privileges of the user account, please refer to **How to Manage User Accounts** on page 47.

## ST7501 LiveClient User Interface




- A. Menu bar                      B. Quick access bar                      C. Device tree  
 D. Camera control panel (PTZ / Two way audio / Instant Playback control panel)  
 E. Status panel                      F. Live video monitoring window                      G. Event window

### Menu Bar



Menu Item	Drop-down Options
<b>System</b>	Lock / Enable Click On Image (Disable Click On Image) / Language / Second View / E-map / Launch Playback / Logout / Exit
<b>Edit</b>	Manually Begin Recording (Manually Stop Recording) / Snapshot / Print / Record to EXE (3GP, AVI) / Find
<b>View</b>	PTZ Panel / Two Way Audio Panel / Instant Playback Panel / Event Window / Full Screen / Minimize
<b>Configuration</b>	Camera Management (Insert Camera / Update Camera / Delete Cameras / Batch Insert Cameras) / User Management / Association Management / Event Management / Station Settings (General Settings / Network Settings / Recording Storage Settings / Recording Schedule Settings / Scheduled Backup Settings / Server Settings / Relay Settings) / Client Settings (Snapshot Settings / Recording Settings / View Settings / General Settings / Joystick Settings / Proxy Settings)
<b>Layout</b>	Start Rotating (Stop Rotating) / Save to / Delete / Choose
<b>Help</b>	About

### Status Panel



User Name
Station Name
Login Time (yyyy-mm-dd hh:mm:ss)
Current Time (yyyy-mm-dd hh:mm:ss)

## Quick Access Bar



Icon	Function	Description
	<b>Exit</b>	Exit the system
	<b>Logout</b>	Log out from the current station
	<b>Lock</b>	Click to Lock the system for security concerns (  Unlock the system)
	<b>Volume</b>	Adjust the audio volume of the current video (  Mute)
	<b>Snapshot</b>	Capture pictures from the focus live video cell
	<b>Print</b>	Print out the pictures of focus live view window or all live video cells
	<b>Record to Media</b>	Record media in EXE/3GP/AVI format (  Recording Media)
	<b>Alert Sound</b>	Play sound when an event triggers
	<b>Switch Screen</b>	Switch the current window to another screen
	<b>Adjust SVC Level</b>	Dynamically adjust the SVC control over frame rates
	<b>Remove All Connections</b>	Remove all live videos from the live view window
	<b>Layout</b>	Change the layout of the live view window
	<b>Full Screen</b>	Maximize the live video cell
	<b>Page Up</b>	Switch to the previous live view page
	<b>Page Down</b>	Switch to the next live view page
	<b>Start / Stop Rotating</b>	Start or stop live view layout rotating




Some buttons will be disabled if the selected devices do not support the related functions.


## Live Video Monitoring Window












The "VIVOTEK" logo is displayed where no camera has been assigned to a video cell.

The red frame ( ) represents the current video cell.




## Device tree






Icon	Description
	A station (The host that's installed with ST7501 Server)
	VIVOTEK fixed network camera Red dot signifies that the camera is recording.
	VIVOTEK PTZ network camera Red dot signifies that the camera is recording.
	VIVOTEK dome network camera Red dot signifies that the camera is recording.
	VIVOTEK fisheye network camera Red dot indicates that the camera is recording.
	VIVOTEK video server Red dot signifies that the video server is recording.
	Digital input on / off
	Digital output on / off
	A layout of the live monitoring window
	A station that's not able to be connected currently.
	A device that's not able to be connected currently.

## Camera Control Panel

### Pan/Tilt/Zoom (PTZ) Control Panel




- There are two types of PTZ control: *Digital (E-PTZ for megapixel cameras)* and *Mechanical (PTZ cameras or fixed cameras with camera control via RS-485)*. If your linked network cameras support PTZ/E-PTZ function, the option(s) will appear on the drop-down list. For detailed camera control settings, please refer to the user's manual of VIVOTEK network camera.
- Click **System > Enable Click On Image** to use the mouse for the control of the PTZ and e-PTZ functions in the video cells for linked cameras. An icon  will appear in the video cell as shown below.



- You can control the PTZ function through joystick as well. For more information regarding to the joystick configuration, please refer to instruction on page 115.

## Two Way Audio Control Panel


The two way audio function allows the user to remotely communicate with people nearby the network camera.



- For detailed information about **How to Use the Talk Panel**, please refer to page 91.
- Only cameras with the two way audio function can be added to the Talk Panel.

## Language Selection

ST7501 currently supports multi-lingual user interfaces including: English, Deutsch, Español, Français, Italiano, 日本語, Português, 简体中文, 繁體中文. If you want to select another language for the interface, please click **System > Language** on the menu bar to select the desired language. Please note that if you want to change the language option, a message will pop up to remind you to restart the system.



If you want to use "User Defined" language, please prepare images and language strings, and upload the files to the following folders:

...|ST7501\Client\LiveClient\language\zz\_UD (language string)  
 ...|ST7501\Client\LiveClient\image (images)





## Event Window

Click **View > Event Window** to open a window showing the real-time information for event triggers. If you want to hide this window, uncheck this option on the menu bar.



The default event window is fixed on the bottom of the LiveClient. If you want to change the event window as a popup page, please click **Configuration > Client Settings > General Settings** to switch the modes.



- The **Type** field in the event window shows the event category and another field **Description** displays the **percentage** of motion in the detection window. You can go to the Configuration setting page of the connected device to set the percentage.

☒ Enable motion detection




For more information about DI/DO settings, please refer to **Association Management** on page 52.



## Instant Playback


Check **View > Instant Playback** to open the window on the panel.



Uncheck this item if you want to hide this window.



Instant Playback Window with slider bar, play, pause, and stop function

The event trigger with recorded data will be attached an icon .

You can **double-click** an event on the list to playback the recorded video. Each event contains about 20-seconds recorded video clip. (The default event recording data is 20 seconds. For more information about event recording, please refer to page 64.)

## Audio Control




The audio function will be enabled if the device is equipped with an internal or external microphone. For detailed audio control settings, please refer to page 136.

## How to Manage Devices


Please follow the steps below to open the Camera Management window:


- Click **Configuration > Camera Management** on the menu bar (or **right-click** the station, then select **Camera Management**).
- Then you can choose to insert, update, delete, or batch insert cameras.



## Insert Devices

Please follow the steps below to add devices to a station:

- Click **Configuration > Camera Management > Insert Camera** on the menu bar (or **right-click** the device/station, then select **Camera Management > Insert Camera**).
- The **Camera Management - Insert** window will pop up. The device tree managed by the station will be displayed in the left Camera List window.
- Enter the **Camera Name**, **address** (or you can enter an **IP address** or a host name by Domain server, and check **Auto** to get a camera name automatically) and configure the **Connection Settings**.
  - If the camera is on the LAN, you can click  **Search Camera** to detect all VIVOTEK network cameras on the LAN. A **Camera List** window will pop up and show a list of detected cameras on the LAN. On the top of **Camera List** window, you can select "**List the cameras which are not inserted**" or "**List all cameras**". The items listed below will then change accordingly. You can click **Mac**, **Address**, **Model**, **HTTP port** to sort the items. Then select a camera from the list to insert to the station.
  - The streaming protocol determines how the live video stream is sent from the camera to the local computer. Please refer to the note on the next page for a detailed description of each transmission protocol. Specify the recommended live monitoring stream for the device. If you want to change the live viewing stream, please refer to page 21 to update the camera settings. Or you can **right-click** the desired cell, then select a desired stream. Please refer to Dual / Multiple Streams on page 34 for a detailed illustration.
  - Click **Detect Model** to detect the device. The Model Name and MAC Address of the device will automatically be displayed in the respective fields if the connection is successful.
- If you want to make sure you are connected to the target device, click **Connection Test** to preview the live video from the device.





- If you want to use "HTTPS Port", please enable the HTTPs settings on the configuration page of the Network Camera first.
- The characteristics of each protocol are shown in the following table:

Protocol	Description
UDP	UDP uses a simple transmission model without implicit hand-shaking dialogues for guaranteeing reliability, ordering, or data integrity. Thus, UDP provides an unreliable service and data grams may arrive out of order, appear duplicated, or go missing without notice. This protocol allows for almost real-time audio and video streams. However, network packets may be lost due to network burst traffic and images may be obscured. Activate UDP connection when occasions require time-sensitive responses and video quality is less important.
TCP	TCP provides the service of exchanging data reliably directly between two network hosts, whereas IP handles addressing and routing message across one or more networks. In particular, TCP provides reliable, ordered delivery of a stream of bytes from a program on one computer to another program on another computer. This protocol guarantees the delivery of streaming data and thus provides better video quality. The downside with this protocol is that the real-time effect is worse than that with UDP for a narrower bandwidth.
HTTP	HTTP is a networking protocol for distributed, collaborative, hypermedia information systems. It's the foundation of data communication for the World Wide Web. This protocol allows for the same quality as TCP and the users need not open a specific port for streaming under some network environment. Users inside a firewall can utilize this protocol to allow streaming data through.
HTTPS	This protocol enables authentication and encrypted communication over SSL (Secure Socket Layer), which protects streaming data transmission over the Internet on higher security level.

e. Configure **Recording Settings**:



- **Recording Stream:** By default, the stream source of the recording stream is stream 1, if you want to change it later on, please refer to page 20 to update the camera settings.
- **Pre-event time:** Enter a number to decide how much time to record before an event is triggered.
- **Post-event time:** Enter a number to decide the duration of recording after an event is triggered.

For example: If both the Pre-event time and Postevent time are set to 10 seconds, a total of 20 seconds video will be recorded if an event triggers. This function is supported by the buffer area of ST7501 server (time shift cache stream).

- **Activity Adaptive Stream (active if possible):** Check this item to enable activity adaptive stream recording and time shift recording. For cameras combined with time-shift cache stream and multiple streams features, user can make use of activity adaptive streaming for dynamic frame control.


If you check Activate Activity Adaptive Stream and enable time-shift cache stream on the camera, only when an event is triggered on the camera will ST7501 Server record the full frame rate streaming data; otherwise, it will only request the I frame data during normal monitoring, thus effectively save lots of bandwidths and storage.




- **Minimum pre-event time:** Due to the limited cache memory of each network camera, the pre-event time of time shift cache stream on camera may be very short. Then you can choose to set pre-event recording on the ST7501 server. For example: To set up minimum 5 seconds. If the cache memory of the selected Network Camera can only support up to 3 seconds, the ST7501 Server will switch to enable pre-event recording for 5 seconds by itself, rather than request the time shift cache stream from the network camera server.




Please note that if you want to enable activity adaptive stream, we suggest you **right-click** the camera on the heirarchical management tree > **Camera Settings > Audio and Video** to activate "**Time Shift Cache Stream**" on the camera and select a stream source. This will help record complete pre-event recording.







- f. The device will automatically be assigned to the default recording group. Uncheck the item if you want to cancel this setting.
- g. When all settings are completed, click **Insert** to add the device to the station. The device will be displayed under the left Camera List.
- h. To insert additional devices to the station, repeat the above steps.
- i. When completed, click **Close** to exit the camera management window.
- j. Back to the main window, you will find the newly-inserted devices displayed under the station and the live video in the video cell.




## Enable SVC

If the camera to-be-added supports the latest SVC (Scalable Video Coding) feature, select the SVC checkbox to enable the related control. The SVC-T feature enables streaming of videos for multiple clients from one single set of IP packets. Designed for saving bandwidth and CPU load on client stations, the frame rate of a video stream appearing through a view cell can be individually adjusted. This feature applies when an administrator experiences unstable video streaming due to the lack of network bandwidth or during an occurrence of network problems.

The ST7501 server (rev. 1.6.1 and later) automatically negotiates with a camera and determines whether a network camera comes with the SVC feature. The SVC checkbox appears if the network camera supports the feature. The same checkbox also appear in the Batch Insert Cameras window.

To configure the SVC-related feature:


1. Right-click on the view cell of an SVC-enabled camera. Select **SVC fps adjust bar**.



2. A slide bar will appear above the view cell. Click and drag the slide bar. A numeric indicator will display the current selection. See below for the frame rates represented by the numeric indicator.

Indicator	Frames per second (fps)
8	30
7	26
6	22
5	18
4	12
3	8
2	4
1	1
0	1/4

If you have multiple SVC-enabled cameras, you can enable a collective setting via the **Adjust SVC level** button on the tool bar. The frame rate selected here will then apply to all view cells on the ST7501 console.




Please note that the SVC related setting can not take effect while the LiveClient station is running the Layout Rotation. Stop the layout rotation before configuring the SVC function.




## Insert a Video Server

1. Left-click on your ST station, and then right-click to display the **Camera Management** command. Let your cursor stay on the command for a second and then move to the **Insert Camera** command. Click on the command to open its configuration window.



2. See below for the steps to insert a Video Server along with its subordinate cameras.




- 2-1. You can uncheck the **Auto** checkbox to enter a name for the Video Server. If set to Auto and your video server already has a name, that name will be displayed in your device list.
- 2-2. Enter the **Address** of the video server - or - use the **Search** button to open a Search window.
- 2-3. If you enter its address and it is found after you click on the **Detect Model** button, its **Model Name** and **MAC Address** will be listed.
- 2-4. Before you click the Detect button, you should enter the **User Name** and **Password** for access to the video server. You should also confirm the **Configuration Protocol**, **Configuration Port**, **Streaming Protocol**, and the rest of the networking parameters.
- 2-5. You may select or deselect the checkbox in front of the recording storage option - or - use the pull-down menu to select the default group or a pre-configured storage group.  
You might use the **Connection Test** button to verify if the stream comes from the device you prefer.
- 2-6. Click **Insert** to include the video server to your configuration.

The Video Server should now be listed on the Camera List.

You can also use the **Search** button to poll the local area network for VIVOTEK's devices. You can select to list all cameras or list those that have not been included in your current configuration.


Click on a device, and its detailed information will immediately appear in the **Camera Management** window on the left. For recording settings, please refer to previous pages.




## Update Devices

Please follow the steps below to update a via Camera Management window:

- Click **Configuration > Camera Management > Update Camera** on the menu bar (or **right-click** the device/station, then select **Camera Management > Update Camera**).
- The **Camera Management - Update** window will pop up. The device tree managed by the station will be displayed in the left Camera List window.
- Select a device from the list you want to update. Its related information will automatically be displayed in the corresponding fields in the Camera Management window. Then you can modify **Connection Settings** and **Recording Settings** of the device.
- After modifying the settings, you can click **Connection Test** to preview the live video from the device.
- When all settings are completed, click **Update** to enable the settings.




b



## Delete Devices from the ST7501 Server


### Delete a device:

**Right-click** the device on the device tree, then select **Delete**. A dialog box will pop up. Click **Yes** to delete the device along with the recorded data; click **No** to delete the device but retain the recorded data; click **Cancel** to cancel the delete action.



### Delete more than one device at a time:

- Click **Configuration > Camera Management > Delete Cameras** on the menu bar (or **right-click** the device/station, then select **Camera Management > Delete Cameras**).
- The **Delete Cameras** window will pop up.
- Select the devices you want to delete from the list, then click **Delete**.
- A dialog box will pop up. Click **Yes** to delete the device along with the recorded data; click **No** to delete the device but retain the recorded data; click **Cancel** to cancel the delete action.
- When completed, click **Close** to exit the **Delete Cameras** window and return to the main window. The deleted device will disappear from the station.




## Batch Insert Devices


Batch insert is a very useful function that allows user to search, filter, and import a row of devices to the station on the LAN at a time. The basic settings can also be applied to those inserted devices simultaneously.

Please follow the steps below to batch insert devices to a station:

- Click **Configuration > Camera Management > Batch Insert Cameras** on the menu bar (or **right-click** the station, then select **Camera Management > Batch Insert Camera**).
- The **Batch Insert Cameras** window will pop up. Then click **Search** to open the Search Camera window.
- On top of the Camera List window, you can select "List the cameras which are not inserted" or "List all cameras". The items listed below will then change accordingly.
- Use the 4 Filters to narrow down the range of the wanted cameras from the list.
  - IP Range: Type in a range of IP address to narrow down the list; the filter automatically filters after you fill in a correct IP range.




- IP with prefix: Type in the prefix of the IP address to narrow down the list.



The screenshot shows the 'Search Cameras' dialog box. Under the 'Filters' section, the 'Address with prefix' checkbox is checked and highlighted with a green box. The text '192.168.5.132' is entered in the adjacent input field. Below the filters, a table lists the search results.

#	Address	Port	Model	MAC
<input type="checkbox"/> 1	192.168.5.132	80	FD8161	00-02-D1-FD-81-15


- Model with prefix: The user can type in the prefix of the model name or the complete model name of the cameras to narrow down the list.



The screenshot shows the 'Search Cameras' dialog box. Under the 'Filters' section, the 'Model with prefix' checkbox is checked and highlighted with a green box. The text 'FD8161' is entered in the adjacent input field. Below the filters, a table lists the search results.

#	Address	Port	Model	MAC
<input type="checkbox"/> 1	192.168.5.132	80	FD8161	00-02-D1-FD-81-15

- MAC with prefix: You can type in the prefix of the MAC address of the cameras to narrow down the list.




The screenshot shows the 'Search Cameras' dialog box. Under the 'Filters' section, the 'MAC with prefix' checkbox is checked and highlighted with a green box. The text '00-02-D1-FD' is entered in the adjacent input field. Below the filters, a table lists the search results.


#	Address	Port	Model	MAC
<input type="checkbox"/> 1	192.168.5.132	80	FD8161	00-02-D1-FD-81-15



- e. When the list is filtered, you can select the cameras one by one or check **Select All** to add them to the batch insert list. Then click **OK** to finish searching.




- f. The selected cameras will be shown on the batch insert camera list with the camera information and the connection status. When you click on a camera, a live view will show up on the right side for you to identify the cameras on the list. If you want to remove a camera from the list, click the trash can icon to delete it.





- g. On the bottom of the window, there is a field for you to alter the camera settings including Connection Settings and Recording Settings. You can apply the new settings to each camera on the list, or click **Apply to All** to apply the same configurations to all the cameras. For more information about Connection Settings and Recording Settings, please refer to Insert Device on page 20 for detailed information.
- h. Specify host: If you want to add a camera to the list, click **Specify Host** to directly add a wanted camera. Click **Add** after filling in the correct information. The camera will be added to the list of the Batch Insert Camera window.
- i. By default, all inserted devices will be applied to the default recording group. Uncheck **Add** if you do not want to assign the selected devices to the default recording group.
- j. Click **Insert** when all the settings are done. The settings will be applied.



**Specify Address**

Address: 192.168.5.131

Configuration Protocol: HTTP

Configuration Port: 80


User Name:

Password:

Add Close



When you modify the camera settings, once the connection information (User Name, Password, Configuration Protocol, Configuration Port, and Streaming Protocol) fails to comply with the network environment, the camera will be disconnected and the status of the camera will become "Camera cannot be found" as shown below.



**Batch Insert Cameras**

Instruction

Search button -> Import into List -> Edit Connection Settings -> Edit Recording Settings -> Insert button

Specify Address button

#	Name	Address	Port	Model	MAC	Status
1	Mega-Pixe...	192.168.5.132	443	FD8161	00-02-D1-FD-...	Camera cannot be found.
2	Mega-Pixe...	192.168.5.131	443	FD8133	00-02-D1-0B-...	Camera cannot be found.
3	Mega-Pixe...	192.168.5.119	443	IP8132	00-02-D1-32-...	Camera cannot be found.

Search... Specify Address...

Camera Name: Mega-Pixel Network Camera

Connection Settings Recording Settings

User Name: Password:

Configuration Protocol: HTTP Configuration Port: 80

Streaming Protocol: TCP Channel: 1

Initial Viewing Stream: 2

Apply to All

Recording Storage


Add the cameras to the recording storage :

(none)

Insert Close

## View Live Videos

The server will automatically add a newly-inserted device to the video cell for live viewing. You also can **double-click** the target device or **drag-and-drop** the target device from the device tree window to the video cell in the live video monitoring window.




## Dual / Multiple Streams

For dual-stream devices, you can **right-click** on the focused cell to select stream 1 or stream 2. For multiple-stream devices, you can select from stream 1 ~ stream 4.



## Fisheye Display Modes


An oval view is displayed by default when a fisheye camera is successfully connected. To display Regional, Panoramic, or the combination of different views, right-click on a fisheye camera's live view to display the associated commands. The display modes available are: 1O (Original), 1P (Panoramic), 1R (Regional), 1O3R (1 Original & 3 Regional), and 4R (Quad Regional) modes.



**Fisheye Display Modes:** below are conceptual drawings for different display modes.


An Original oval view covers the hemisphere taken by the fisheye lens.

### 1O View (Original View)



A Regional view crops a portion of the hemisphere as a region of interest. You can zoom in or out or move to other view area from on the regional view.

### 1R View (Single Regional View)




**1P** (Single Panoramic) Display mode:

With image correction firmware algorithms, the hemispheric image is transformed into a rectilinear stripe in the 1P display mode. Viewers can use the PTZ panel or simply use mouse control to quickly move through the 360° panoramic view.


Note that the 1P view is apt for an overview, the Zoom in/out function does not apply in this mode.

### 1P (Panoramic) Mode Screen Control



Fisheye cameras also support multiple regional views from within the same hemisphere, and they can be displayed with or without an Original view in its view cell.

## 3R View (Regional View)



\* Only two regional views are shown for simplicity reason




Note that the "Mount type" setting also determines the display modes available to your display modes. Please refer to fisheye camera's User Manual.

A highly versatile mouse control is implemented with fisheye cameras. The same control takes effect both on a browser management session and the ST7501 LiveClient utility. See the sample drawings below for how it works.

You can click and hold down the left mouse button to quickly swipe through the field of view, change the view angle, or use the mouse wheel to zoom in/out on a region of interest. However, the PTZ mouse control is only available in the **"R" (Regional) mode**. In the **Panoramic mode**, you can only scroll the 360° panoramic view.

### 103R (Original & Regional) Mode Screen Control



More display modes are available with the VAST server versions. In the Playback utility, similar display modes are also available. Only that the mouse control is not available in a playback window.




The various display modes require the support of D3D technologies by your display card on the ST7501 station. Most off-the-shelf display cards today support this feature.

The onscreen mouse control is very agile. Therefore, use the PTZ panel for more delicate moves in the field of view. Pan and Patrol moves are also supported if you have configured preset PTZ positions in the camera's firmware. Note that the Pan move takes place in the Panoramic and Regional views, while the Patrol function through preset positions applies only in the Regional views.


## Refresh

**Right-click** the device, then click **Refresh**, the camera information will be refreshed from the server.




## Streaming Server

**Right-click** the station or the device and click **Output Streaming URL**. A .txt file with streaming URL will pop up. Then you can use this URL to link to the live streaming through QuickTime Player.




## Camera Settings

**Right-click** the device, then click **Camera Settings** to open a web browser's session to the camera.




*You must have an IE browser rev. 6.0 or above for the management session.*




## Remove Live Video from the Video Monitoring Window

There are two ways to remove a live video from the video cell:

Method 1. **Right-click** the video cell and select **Remove**.



Method 2. **Drag-and-drop** the live view from the video cell to the device tree window.



*If you want to remove all live videos from the video cells, please click  on the menu bar.*





## How to Change the ST7501 LiveClient Layout

### Changing the Layout of the Live Video Monitoring Window


VIVOTEK ST7501 LiveClient supports up to 32-CH simultaneous video viewing on a single monitor and allows you to change the layout of the live video monitoring window based on the number of inserted devices.

#### Switch Video Channels


To move a video channel to another empty video cell, **drag-and-drop** the view to the target video cell.











To switch two different channels, **drag-and-drop** one view to the other, then the two different channels will be switched to the opposite.



#### Configure Layout Mode

Click the **Layout** button  on the quick access bar. Select a desired layout mode, and the layout window will be changed accordingly. Below we illustrate 8 types of layout modes and the corresponding page numbers:





Layout mode	Description	Video page
1 x 1		32
2 x 2		8
1 + 5		4
3 x 3		3
1 + 12		2
4 x 4		2
5 x 5		1
1 + 31		1


More than 1 video page;  
rotation function is enabled

Only 1 video page;  
rotation function is disabled


Some layout modes (1 x 1, 2 x 2, 1 + 5, 3 x 3, 1 + 12, 4 x 4) will divide all video channels into several pages.

For example, under 3 x 3 layout mode, you can switch among the pages by clicking  and  on the quick access bar. To arrange the content of each page, manually **drag-and-drop** cameras from the device tree to the video cells on each page.


Page 1



Page 2








Page 3




### Rotating Video Pages



For layout modes that contain more than one page, ST7501 LiveClient offers the rotating function for displaying all video pages in turn.

- To enable this function, click  on the Quick Access Bar, which will become  **Stop Rotating**, and the video pages will start to rotate so that the user does not have to click  to move to the next page.
- To disable this function, click  **Stop Rotating**, which will become  on the Quick Access Bar.

You can also click **Layout > Start to Rotate/Stop Rotating** to enable/disable this function.





The default rotating time interval is 6 seconds. If you want to edit rotation settings, please refer to **Rotation Settings** on page 113.

### Edit Layout

Please follow the steps below to save a layout:

- Arrange a layout mode and drag devices to their desired video cells.
- Click **Layout > Save to > New** on the menu bar. A **Layout Name** dialog box will pop up.




- Enter a name for the the layout, then click **OK** to enable the setting.


- d. Back to the monitoring window, the new layout will be displayed under the device tree as shown below. You can save up to 10 layouts.
- e. To change to another layout, **double-click** the layout items on the device tree, or click **Layout > Choose** on the menu bar to select a desired layout.




- If you want to edit an existing layout, arrange a layout mode and drag devices to the desired video cells, then click **Layout > Save to > New** to save as a new layout or an **existing layout** to replace with the new one.



- If you want to delete an existing layout, **right-click** the layout item on the device tree or click **Layout > Edit > Delete** on the menu bar to delete it.





*Whenever you close the LiveClient or Playback programs and changes in screen layout have been made, you will be prompted to save your current configuration.*



## Maximize/Minimize the Live Video Monitoring Window

- Single View: to maximize a video cell to the entire live video window


**Double-click** the video cell, or **right-click** the video cell and select **Single View**. The focused video will occupy the entire playback window as shown below.




To restore to the original layout, **double-click** the video cell or **right-click** the video cell and uncheck **Single View**.



- **Full Screen:** Maximize the live video monitoring window to the entire screen

Click **Full Screen**  on the quick access bar or **right-click** the video cell and select **Full Screen**. In addition, you can also click **View > Full Screen** on the menu bar to maximize the live video monitoring window.

To restore to the original layout, you can **right-click** a video cell and uncheck **Full Screen** or click the **Esc** button on the keyboard to exit full screen mode.




- **Minimize:** If you click **View > Minimize** on the menu bar, LiveClient will minimize to the Windows tool bar.


## View Live Video on Dual Monitor

ST7501 also supports live video viewing on dual monitors, allowing you to manage maximum 32 channels on two screens concurrently. Moreover, the layout of the video monitoring window on different monitors can be set up individually.

Please follow the steps below to set up dual-screen mode:

- Set up dual monitors for your local computer.
- Launch ST7501 LiveClient on monitor 1.
- Click **System > Second View** on monitor 1, then the live video monitoring window will be displayed in monitor 2 as shown below.




- There are two ways to view live videos. One is to **drag-and-drop** the target device from the device tree window to the video cells. The other is to click any video cell on monitor 1 or monitor 2, then **double-click** the target device; the live video will be displayed in monitor 1 or 2 in accordance with your selection.
- If you click **Switch Screen**  on the quick access bar, the live monitoring window on monitor 1 and monitor 2 will swap.

## View up to 32 channels simultaneously

If you select 4x4 layout on dual screens, you can view a maximum of 32 channels live video simultaneously. In this case, each layout contains 32 channels on 1 video page.




Monitor 1 - 16 channel




Monitor 2 - 16 channel



## Using different layouts on each monitor

You also can select different layout for two monitors, simply click the **Layout** button  on the quick access bar. Below is an example of the 2x2 layout with 4 video pages on monitor 1 and the 4x4 layout with 1 video page on monitor 2. You can click  and  to switch among the video pages.


Monitor 1 - page 1



Monitor 2 - page 1



Monitor 1 - page 2





•  
•  
•


Monitor 1 - page 4


## View Live Video with Multiple Monitors

If you have multiple screens in your monitoring center, you can switch the ST7501 LiveClient Window among these screens.

- If you have two monitors, click **Switch Screen**  on the menu bar; the LiveClient window on monitor 1 will switch to monitor 2.



- If you have three or more monitors, a drop-down list will be displayed when you click **Switch Screen**  on the menu bar. The number of items on this list depends on the number of your screens. Select a desired screen on the drop-down list and the LiveClient Window will switch to the specified screen.





## How to Manage User Accounts

ST7501 allows users to apply multiple user accounts to a station with five levels of user roles: Administrator > Power User > User > Operator > Guest. Each role has different permissions listed as shown below. Moreover, Administrators have the highest privileges, while Power Users can only add/edit users as Power Users, Users, Operators, and Guests.

### The Default User Roles and Permissions of User Accounts



Functions \ User Roles	Administrator	Power User	User	Operator	Guest	Description
User Management	✓	✓	✓			Manage user accounts
Camera Management	✓	✓				Insert and configure the camera settings
Association Management	✓	✓	✓			Access and modify the association settings
Access Event Management	✓	✓	✓			Access event management
Modify Event Management	✓	✓	✓			Modify event management
General Station Settings	✓	✓				Modify general station settings
Station Network Settings	✓	✓				Modify network settings
Access Recording Storage/ Recording Schedule Settings	✓	✓	✓	✓		Access the recording group and recording schedule
Modify Recording Storage/ Recording Schedule Settings	✓	✓	✓			Configure the recording group and recording schedule
Manually Record	✓	✓	✓	✓		Enable the recording function manually
Scheduled Backup Settings	✓	✓	✓			Configure backup schedule
Access Server Settings	✓	✓	✓			Access server settings
Modify Server Settings	✓	✓	✓			Modify server settings
Relay Management	✓	✓				Allow user to manage station relaying settings
Client Settings	✓	✓	✓	✓		Configure the client settings: snapshot, AVI, etc.

Privileges \ User Roles	Administrator	Power User	User	Operator	Guest	Description
Modify Directories	✓	✓	✓			Add, remove and rename directories
Delete Camera	✓	✓				Delete camera from the station
PTZ Control	✓	✓	✓	✓		PTZ control for PTZ cameras and speed domes in LiveClient
Device Control	✓	✓	✓	✓		Control the digital output or white light/IR illuminators of the cameras
Talk Control	✓	✓	✓	✓		Two way audio function for the cameras
Access Camera Configuration	✓	✓	✓			Access the camera settings
Modify E-map	✓	✓	✓	✓		Allow user to modify the E-map
Event Search	✓	✓	✓	✓		Use built-in search engine to search specific events
Log Viewer	✓	✓	✓	✓		Use built-in search engine to search the log
Backup	✓	✓	✓	✓		Back up database manually
Record/Export Media	✓	✓	✓	✓		Record live stream or export playback stream to local files
Playback Authority	✓	✓				Allow user to access Playback



## Manage a User Account

### Add a New User Account

- a. Click **Configuration > User Management** on the menu bar (or **right-click** the station, then select **User Management**).



- b. The **User Management** window will pop up. The user accounts under the station will be displayed under the left User List tree.
- c. Enter the **User Name**, **Password**, and specify the **User Role** of this user.
- d. Click **Add** to add the user account to the station. It will be displayed under the User List.




## Permission of the User Account


Administrator is granted with all access privileges, while other user roles' permission is limited. If you want to modify the permission, please login as the Administrator to configure the settings.

e. Select a User account from the User List tree.

f. If you want to set the limit of the permission of the user, click **Permission** tab to check or uncheck the items.



g. If you want to limit the devices accessible by the user, click **Accessible Cameras** tab to select the desired devices.






If you want to remove access permission mentioned above from the account, the user will not be able to operate some functions listed in the following warning dialog.



h. When completed, click **Update** to enable the new settings.

### Delete the User Account

i. Click **Delete**, a delete user dialog will pop up. Click **OK** to delete the user account.



If the Administrator modifies or deletes the User Account, that modified user might be kicked off from the station.


## How to Set up Association Management

ST7501 LiveClient supports association management which allows the user to configure relative event trigger notifications of connected network devices. (Eg. DI/DO status on the device tree, motion detection windows appear in the video cell, the event list in the event window)

### Association Management




Please follow the steps below to configure association settings:

- a. Click **Configuration > Association Management** on the menu bar (or **right-click** the station and select **Association Management**).



- c. The **Association Management** window will pop up. Check or uncheck the items and click **Save** to enable the settings. The items you've selected will also be displayed under the device tree.


For example:





- d. If you want to rename the DI device, select the DI item and click the **Rename** button. It will be very convenient for you to recognize the target DI device.



- To manually enable DI/DO settings, please **right-click** the video cell and select **Set DO** to enable (**Trigger**) or disable (**Normal**) the digital output of the linked device.



- Before you configure the DI/DO Settings for ST7501, please enable DI/DO settings on your network device and set up the camera correctly on the configuration page. You can **right-click** the device and click **Camera Settings** to open the configuration page.






## How to Set up Event Management

ST7501 LiveClient supports event management which allows the server to respond to particular situations (events).


### Event Management

Please follow the steps below to configure event management:


- a. Click **Configuration > Event Management** on the menu bar (or **right-click** the station and select **Event Management**).




- b. The **Event Management** window will pop up. Click **New** to set up a new event. When you finish the general settings, click **Next** to set up trigger source settings.




- c. Click **Add** to select the trigger source by Device or Trigger Type.



- d. The Device List window will pop up. Select one or more devices and set the Notification Type. Depending on the trigger source, the Notification Type will be different. Then click **OK** to close the window.




- e. The trigger source(s) will be listed on the window as shown below. If you want to add more Trigger sources, click **Add** and repeat d.~e. Then click **Next** to assign action(s) to the trigger source(s).
- f. Click **Add** to open the **Action Settings** window.





There are several types of Action Settings.



- Email: The server will send a notification via e-mail when a trigger is activated.
  - g. To enable this function, please set up the SMTP server first. Click **SMTP Setting** to open the window and refer to page 89 for detailed information.
  - h. Enter the related information. You can modify the mail content in the blank. If you want to modify the content, click **Insert Macro** to select the parameter. When completed, click **OK** on the bottom to enable the setting.




- Start to record on: The sever will start to record video from selected camera(s) when an event is triggered.
  - i. Click **Add Camera** to select the target camera(s).
  - j. The selected camera(s) will be listed on the left window below. When completed, click **OK** on the bottom to enable the setting.



- Move to preset location: The target camera(s) will move the shooting area to the preset location(s) when an event is triggered.
  - k. To enable this function, please set preset locations on the camera configuration page first.
  - l. Click **Add Location** to select preset location(s).
  - m. The selected preset location(s) will be listed on the left window below. When completed, click **OK** on the bottom to enable the setting.



- Set DO: Select this option to turn on external digital output device(s) when an event is triggered. For more information about how to set DI/DO settings on the target camera, please refer to page 52.
  - n. Click **Add DO** to select DO decive(s) and select a DO status (Normal or Trigger).
  - o. The selected DO device(s) will be listed on the left window below. When completed, click **OK** to enable the setting.



- GSM Short Message: The sever will send a short message to a GSM cell phone when an event is triggered.
- p. Please enter the Phone Number and open **GSM Settings** window to set related information if necessary. When completed, click **OK** to enable the setting.

Please enter the country code if you use overseas call.

- HTTP: This function allows user to send a CGI command to the linked network camera, such as pan/tilt/zoom function or enable DO devices.
- q. You can click **Insert Macro** to select the parameter. Please enter authentication information if necessary. For example: `http://192.168.3.66/cgi-bin/admin/setparam.cgi?system_hostname=$(EventTime)$(CameraName)`  
If you want to use special characters such as \$-\_.+!\*(),#%+\$,@,;/?=&, please refer to the following table to transfer the Code (Hex).  
For example: `http://192.168.3.66/cgi-bin/admin/setparam.cgi?system_hostname=123&456`  
--> `http://192.168.3.66/cgi-bin/admin/setparam.cgi?system_hostname=123%26456`


Character	Code (Hex)
!	21
#	23
\$	24
%	25
&	26
'	27
(	28
)	29
*	2A
+	2B

Character	Code (Hex)
,	2C
-	2D
.	2E
/	2F
:	3A
;	3B
=	3D
?	3F
@	40
_	5F
~	7E

r. The action(s) will be listed in the window as shown below.

Then click **Next** to set up schedule(s) to the action(s).

For more information about **Schedule Settings**, please refer to Recording Schedule Settings on page 66. You can assign more than one time frame to one action.




**New Event**

General >> Trigger >> **Action** >> Schedule >> Detail

Start to record on 2\_IP8330  
Move 3\_PZ71x1 to right  
Move 3\_PZ71x1 to left  
Turn DO-1 (1\_FD8161) to Tripper

Add Remove

Back **Next** Finish Cancel



**New Event**


General >> Trigger >> Action >> **Schedule** >> Detail

Load Template Save as Template

Time Frame	Rule
Always	Weekly Setting (Day-based)

Add Edit Delete Up Down

Back **Next** Finish Cancel



**Time Frame**

Time Frame Name: Always Load Template Save as Template Save

Repeat Frequency: Weekly Setting (Day-based)

**Weekly Setting (Day-based)**

Set time segments in a 24-hour day. Multiple segments are allowed.

0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23

Start Time: 00:00 End Time: 00:00 Add Delete


Repeat on: ☒ Sunday ☒ Monday ☒ Tuesday ☒ Wednesday ☒ Thursday ☒ Friday ☒ Saturday

Range:


Start: 2008/12/ 8 End: ☐ 2035/ 1/ 1 ☒ Never Stop

Repeat every: 1 Week(s)


- s. When you finish schedule settings, click **Next** to review the detailed information of the new event settings.



- t. Following is the detailed information of the new event setting. You can click **Back** to modify the event setting or click **Finish** to close the window.



- u. Following is an example of an enabled event. You can click **New** to set up more events or click **Close** to exit the window.




Click to disable or modify the selected event



## How to Configure the Station General Settings

Select the target station from the device tree, then click **Configuration > Station Settings > General Settings** on the menu bar (or **right-click** the station on the device tree and select **Station Settings > General Settings**). The **Station General Settings** window will pop up.



### Server Settings


In this section, you can modify the Station Name.

### Log Settings

In this section, you can set up **Log Settings** for the station.


The ST7501 server allows user to search for the recorded log through ST7501 Playback. For more information, please refer to **How to Search Logs** on page 153.

- **Log level:** Select **High** (only record high-level logs), **Normal** (record high-level and normal-level logs), **Low** (record all logs). For detailed information about log levels, please refer to page 154.
- **Reserve Time:** Enter the time interval that you want to reserve the log record. The maximum value is 365 days.



## How to Configure Station Network Settings

Select the target station from the device tree, then click **Configuration > Station Settings > Network Settings** on the menu bar (or **right-click** the station on the device tree and select **Station Settings > Network Settings**). The **Network Settings** window will pop up.



### Port Settings


- **Server port:** The default server port is set to 3454. If you change the server port, please enter the new value while logging the LiveClient next time.
- **RTSP port:** The RTSP (Real-Time Streaming Protocol) controls the delivery of streaming media. By default, the port number is set to 554.

### UPnP Settings

- **Enable UPnP port forwarding:** For client to access the ST7501 Server from the Internet, select this option to allow the server to open ports on the router automatically so that video streams can be sent out from a LAN. To utilize of this feature, make sure that your router supports UPnP™ and it is activated.
- **Enable UPnP presentation:** If you select this option, shortcuts to ST7501 server will be listed in My Network Places.

### Proxy Settings

In this section, you can enable, modify, or cancel **Proxy Settings** for ST7501 Server if your network devices are set up under a proxy.



## How to Edit Recording Groups


By default, all devices are assigned to the default recording group. You can manually remove a device from the default recording group. However, only those devices which belong to a recording group can produce recorded media files.

Another purpose of setting recording group is that you can divide all the managed devices into several recording groups, and for each recording group, you can assign several hard-disks (with recording paths) to store media data. The live media data will be stored in the first assigned hard-disk initially, and when the available space of the first hard disk reaches the preset reserved space limit, the media data will be stored in the second disk and so on. If the available space of the last disk approaches the reserved space, the recorded files in the first disk will be erased and overwritten with new media data. This procedure is called "Cyclic Recording".

### Recording Storage Settings



Please follow the steps below to set up recording groups for a station:


- Click **Configuration > Station Settings > Recording Storage Settings** on the menu bar (or **right-click** the station on the device tree and select **Station Settings > Recording Storage Settings**). You can also **right-click** **DefaultGroup** under the station and click **Recording Storage Settings** since all devices are assigned to the **Default Recording Group** by default settings.








- The **Recording Storage Settings** window will pop up.



## Default Storage Group Settings


The following example shows the default storage group settings. You can click  **Rename** to modify the group name or click  **Delete** to remove the default settings.



- c. The default recording path is **C:\Recording**. The total space and free space of the disk is shown on the right for reference.
- d. Add Local Path: Click  to add another recording path on your local computer. A Select Path dialog will pop up as shown below. When all settings are complete, click **OK** to enable the settings, or click **Cancel** to discard the settings.
- e. Add Network Path: Click  to add a network storage for recorded data. Please refer to page 88 for detailed information about how to add a new network storage server. Then double-click the **Path** to assign a specific folder as a new recording path.



- f. To modify the settings of a path, select the path from the list, then click  **Change settings** to modify.
- g. To delete a path, select the path from the list and click  **Delete path**. A warning dialog box will pop up as shown below.



- h. By default, all devices are assigned to the **Default Recording Group** in the window on the right. You can select device(s) from the list and click << to delete device(s) (or **right-click** the device under DefaultGroup tree to delete it). Note that a **Delete Camera** dialog box will pop up. Click **Yes** to delete the device along with the recorded data; click **No** to delete the device but retain the recorded data; click **Cancel** to cancel the delete action. Please note that only those designated devices can record videos.
- i. Click >> to add devices to the **DefaultGroup**.

**j** ☐ Delete recorded data older than  day(s)


Cameras in Storage Group




Available Cameras:


Name	Address	Group
1_FD8161	192.168.5.132	DefaultGroup


Added Cameras (1/32):


1\_FD8161

**h** **i** 

**k**   

**h** 




- Recording Storage
  - DefaultGroup
    - 1\_FD8161
    - 2\_IP8330** (selected)
      - h** 
      - Start Manual Recording
- Layout

- j. Delete recorded data older than the duration: If you only want to retain recorded data for a duration, check this item and enter a number of day(s). In addition, since ST7501 Server will do "cyclic recording" automatically, the oldest file will be overwritten by the latest one when the maximum capacity is reached.
- k. When completed, click **Apply** to confirm and save your settings. If you want to cancel all of your editing, click **Restore** to return to the previous settings or click **close** to discard the settings.




## Add New Recording Group(s)

If you want to add a new recording group, click  **Add** to give a name to the new recording group, which will be displayed on the drop-down list.





The following is an example of recording group list.



**Recording Storage for VVTK\_Station1**

Storage Group: Recording Group   

Paths in Storage Recording Group 1  
Recording Group 2  
Recording Group 3

C:\Recording

**Storage Information**

Total: 58.59 GBytes  
 Reserved: 2.00 GBytes  
 Free: 12.10 GBytes

☐ Delete recorded data older than 7 day(s)

Cameras in Storage Group

Available Cameras:

Name	Address	Group
01_IP7138_6C	192.168.3.36	Recording Gr...
02_IP7151_84	192.168.3.37	Recording Gr...
03_I27151_33	192.168.3.38	Recording Gr...
04_IP7251_34	192.168.3.39	Recording Gr...
05_IP7142_D5	192.168.3.40	Recording Gr...
06_IP7130_A6	192.168.3.81	Recording Gr...
07_IP7330_20	192.168.3.225	Recording Gr...
08_IP7133_93	192.168.3.83	Recording Gr...
09_IP7131_B7	192.168.3.84	Recording Gr...
10_IP7135_12	192.168.3.85	Recording Gr...

Added Cameras (1/32):

01\_IP7138\_6C  
 02\_IP7151\_84  
 03\_I27151\_33  
 04\_IP7251\_34  
 05\_IP7142\_D5  
 06\_IP7130\_A6  
 07\_IP7330\_20  
 08\_IP7133\_93  
 09\_IP7131\_B7  
 10\_IP7135\_12



Please refer to the following limits when you set up recording group(s):


- The maximum number of devices in a recording group is 32-CH.
- One recording group can be assigned with several recording paths and do cyclic recording; while one recording path should only be assigned to one recording group.



## How to Edit Recording Schedules

After editing recording storage settings, you can begin to edit recording schedules for the devices in a recording group. By default, all devices are assigned to the default recording schedule (Please refer to the default time frame settings on page 70). Therefore, once you insert a device to the station, the ST7501 Server will begin to record live video according to the default recording schedule. You can also manually remove a device from the default recording schedule. Please note that **you cannot assign recording schedules to those devices which have been deleted from a recording group**.

The following is an illustration of a set of recording schedules, which are composed of several time frames. Each time frame has its own time segments, period of time, repeat interval, and recording mode. You can create different recording schedules with simple or complex time frames based on your needs.



In addition, you can arrange the priority of each time frame according to its importance. The recording schedule with the highest priority will be applied first. This capability is very useful because you can specify a new time frame with the highest priority temporarily without modifying the other time frames.

Features of the recording schedules:

- Each device can be assigned to only one recording schedule.
- Each recording schedule may contain many time frames.
- Each time frame has its own repeat frequency and recording mode.


To save time editing recording schedules and time-frames, we also provide a useful **template** function to save your time on schedules/time-frames settings. That is, you can save a specified schedule and download it as a template for future use or upload a well-arranged schedule template designed by others.

Please note that after you save the recording settings in the server, the recording schedule will begin automatically according to your settings.

## Edit Schedule List

Please follow the steps below to set up the recording schedules:

- a. Click **Configuration > Station Settings > Recording Schedule Settings** on the menu bar (or **right-click** the station and select **Station Settings > Recording Schedule Settings**).



- b. The **Recording Schedule Settings** window will pop up. By default, all cameras under the station are assigned to **Default Schedule**, **Default Time Frame**, and **Default Camera List**.

### Add Schedules



- c. To add a new recording schedule, click **Add** to enter a name in the Schedule Name dialog box for the new schedule. Click **OK** to confirm the settings or **Cancel** to discard the settings. The new recording schedule will be displayed on the schedule drop-down list.

### Rename Schedules

- d. To rename an existing schedule, select the schedule from the schedule drop-down list and click **Rename**. A Schedule Name dialog will pop up for you to fill in a name for the new schedule. Click **OK** to confirm the settings or **Cancel** to discard the settings. The new recording schedule will be displayed on the schedule drop-down list.



### Delete Schedules

- e. To delete an existing schedule, select the schedule from the schedule drop-down list and click **Delete**. A Remove Schedule dialog box will pop up. Click **OK** to confirm or **Cancel** to discard the settings.



## Load/Save Schedule Templates

- f. If you have a schedule template with time frame settings, you can upload it to simplify the editing of the schedule. Click **Load Template**, and a **Load File** dialog box will pop up. Select the template file and click **Open** to load.
- g. If you want to save a schedule as a template for future use, select the schedule from the schedule drop-down list and click **Save as Template**. A **Save File** dialog box will pop up for you to save the template file.



## Edit Camera List

Please follow the steps below to assign a device to a recording schedule:

- Select a recording schedule on the schedule drop-down list.
- By default, all devices under the station are assigned to the **Default Schedule**.
- Click << to remove devices from the **Default Schedule**. Click >> to add devices to the **Default Schedule**.
- Click **Apply** to confirm or **Close** to discard the settings.

**Recording Schedule for VVTK\_Station1**

Schedule List: Default Schedule (dropdown) | Add | Rename | Delete | Load Template | Save as Template

**Time Frame List**

Time Frame	Rule
Always	Weekly Setting (Day-based)

Add | Edit | Delete | Up | Down

**Recording Settings**

Recording Mode: Continuous (dropdown)

**Triggers**

☐ Motion ☐ IVA ☐ PIR ☐ Tampering

**Digital Input**

☐ Trigger State ☐ Normal State

**Camera List**

Name	Address	Group	Scheduled
1_FD8161	192.168.5.101	DefaultGroup	Yes
2_IP8330	192.168.5.102	DefaultGroup	Yes
3_PZ71x1	192.168.3.101	DefaultGroup	Yes

>

**1\_FD8161**  
**2\_IP8330**  
**3\_PZ71x1**

Apply | Close



If you add a Network Device that does not belong to any Recording Group, a warning dialog will pop up as shown below. For more information about how to set up Recording Group(s), please refer to Recording Group Settings on page 62.

**Camera List**

Name	Address	Group	Scheduled
1_PZ7131	192.168.3.247	DefaultGroup	Yes
2_IP8161	172.16.200.40	DefaultGroup	No

**Error**


The camera is not in recording group.

OK


Apply | Close

## Edit Time Frame List

Default Time Frame: Weekly (Day-based), Mon.~Sun., 24-hour, continuous recording




Click **Edit** to open the Default Time Frame settings page as shown below.




## Add New Time Frames

Please follow the steps below to add new time frames to a schedule:

- Select a recording schedule from the drop-down list.
- Click **Add** to open the **Time Frame Settings** window.



- Enter a name for the new time frame.
- If you have a time-frame template, you can upload it to simplify the editing of the schedule. Click **Load Template** and the **Load File** dialog box will pop up. Select the template file to load.
- To edit the new time frame, select a **Repeat Frequency** from the drop-down list and edit the time segments, applicable days, applicable period of time, and repeat time interval. For the detailed settings of each repeat frequency, please refer to **The Concept of Repeat Frequency** on page 73.
- When completed, click **Save** to enable the settings.
- If you want to save this time frame as a template for future use, click **Save as Template**. A **Save file** dialog will pop up for you to save the template.





- h. If you want to add additional time frames to the schedule, repeat the steps above.
- i. Close the window when you finish the time frame settings.
- j. Back to the Recording Schedule Settings window, the new time frame will be displayed on the Time Frame List.
- k. If you want to edit an existing time frame, select it from the Time Frame List and click **Edit** to set up.
- l. If you want to delete an existing time frame, select it from the Time Frame List and click **Delete**.
- m. If you want to change the priority of a time frame, select it from the Time Frame List and click **Up** or **Down** to shift its position. The time frame on the top of the list has the highest priority.

**Recording Schedule for VVTK\_Station1**

Schedule List: Default Schedule [Add] [Rename] [Delete] [Load Template] [Save as Template]

**Time Frame List**

Time Frame	Rule
Always	Weekly Setting (Day-based)
Time Frame 2	Weekly Setting (Periods in a week)

[Add] [Edit] [Delete] [Up] [Down]

**Recording Settings**

Recording Mode: Event

**Triggers**

☒ Motion ☒ IVA ☒ PIR ☒ Tamper

**Digital Input**

☒ Trigger State ☒ Normal State

**Camera List**

Name	Host	Group	Scheduled
1_FD8161	192.168.5.101	DefaultGroup	Yes
2_IP8330	192.168.5.102	DefaultGroup	Yes
3_PZ71x1	192.168.3.101	DefaultGroup	Yes

1\_FD8161  
2\_IP8330  
3\_PZ71x1

[Apply] [Close]


## Recording Settings

- n. Select one of the following Recording Modes for the time frame:
  - **None**: No recording action.
  - **Continuous**: 24-hours continuous recording. If you want to enable Activity Adaptive Streaming, please refer to page 22 for detailed illustration.
  - **Event**: The server will start to record only when an event is triggered. The recording time length depends on the settings in Recording Group Settings. The default time length is 20 seconds (10s pre-event time plus 10s post-event time). Please refer to page 64 for more information. For more information about event categories, please refer to page 148 for detailed illustration.
- o. Select Trigger Source(s): Motion Detection, IVA (Intelligent Video Analysis), PIR, and Tamper Detection
- p. Select the status of Digital Input(s): Trigger State or Normal State
- q. Click **Apply** to confirm the settings. Then close the window when you finish the recording schedule settings.




The following diagrams show the frame rate variation of two recording modes:

1. Continuous recording + Activity adaptive recording (help save bandwidth and storage)



2. Event recording



## The Concept of Repeat Frequency

ST7501 offers the following types of repeat frequency. The definition of each type is listed in the following table:

Repeat Frequency	Discription
Daily Setting	<ul style="list-style-type: none"> <li>Specify arbitrary time segments within a day,</li> <li>Repeat the segments every N days in the specified period of time</li> </ul>
Weekly Setting (Day-based) (Default Time Frame)	<ul style="list-style-type: none"> <li>Specify arbitrary time segments within a day,</li> <li>Apply only on selected days of a week,</li> <li>Repeat the segments every N weeks during the specified period of time.</li> </ul>
Weekly Setting (Periods in a week)	<ul style="list-style-type: none"> <li>Specify arbitrary time segments within a week,</li> <li>Repeat the segments every N weeks during the specified period of time.</li> </ul>
Monthly Setting (Day-based)	<ul style="list-style-type: none"> <li>Specify arbitrary time segments within a day,</li> <li>Apply only on selected days of a month,</li> <li>Repeat the segments every N months during the specified period of time.</li> </ul>
Yearly Setting (Day-based)	<ul style="list-style-type: none"> <li>Specify arbitrary time segments within a day,</li> <li>Apply only on selected days of a year,</li> <li>Repeat the segments every N years during the specified period of time.</li> </ul>

## Repeat Frequency: Daily Setting

To set up daily repeat frequency, please configure the following items: Daily time segments, applicable period of time, and repeat time interval.

**Time Frame**

Time Frame Name:  Load Template Save as Template Save

Repeat Frequency: **Daily Setting**

**Daily Setting**

Set time segments in a 24-hour day. Multiple segments are allowed.

**Daily timeline control bar**

Start Time: 00:00 End Time: 00:00 Add Delete

Range:

Start: 2010/ 1/27 End: ☐ 2010/ 1/27 ☒ Never Stop

Repeat every: 1 Day(s)

**Daily time segments**  
\*You can drag the daily timeline bar for more than one time segment per day.

**Applicable period of time**

**Repeat time interval**

## Set up daily time segments

You can specify several time segments within a day. The numbers 0~23 on the **hourly timeline control bar** (the purple rectangles) represent the 24 hours in a day.

There are two ways to define time segments: one is to use the computer mouse to manipulate the timeline control bars; the other is to fill in the precise start and end time values in the corresponding fields.

### Add time segments: Choose either step 1 or step 2 to set up

1. Use the mouse to drag the timeline bars:

- Left-click the daily timeline control bar** (the purple rectangles) and drag the mouse.
- The corresponding time segment will also appear in the Start Time and End Time fields. Click **Add**, then the red timeline bars representing new time segments will appear as shown below. You can drag multiple time segments within a day.

In the following illustration, the yellow arrows show the dragging direction of the mouse. You can drag from left to right or the opposite.

Start Time: 08:00 End Time: 19:00 Add Delete

2. Fill in the precise Start Time and End Time:

- Directly enter the value in the Start Time and End Time fields, then click **Add**.
- The corresponding red timeline bar will automatically appear as shown below.

The screenshot shows a timeline from 0 to 23. A red bar is highlighted from 08 to 19. Below the timeline, the Start Time is set to 08:00 and the End Time is set to 19:00. The 'Add' button is highlighted with a green box, and the 'Delete' button is also visible.

**Delete time segments:** Choose either step 1 or step 2 to set up

- Use the mouse to erase the timeline bar: **Right-click** on an existing red timeline bar and drag the mouse. A green timeline bar representing the deleted part of the time segment will erase the red bar as shown below.

In the following illustration, the green arrows show the dragging direction of the mouse. You can drag it from left to right or the opposite.

The screenshot shows a timeline from 0 to 23. A red bar is highlighted from 08 to 19. A green bar is shown erasing the red bar from 12 to 14. Below the timeline, the Start Time is set to 08:00 and the End Time is set to 19:00. The 'Add' and 'Delete' buttons are visible.

The screenshot shows a timeline from 0 to 23. A red bar is highlighted from 08 to 19. A green bar is shown erasing the red bar from 12 to 14. Below the timeline, the Start Time is set to 12:00 and the End Time is set to 14:00. The 'Add' and 'Delete' buttons are visible.

2. Use the delete button to remove the entire timeline bar:



- Click an existing red timeline bar or **left-click** the **daily timeline control bar** (the purple rectangles) and drag the mouse.
- The corresponding time segment will appear in the Start Time and End Time fields.
- Click **Delete**, and the selected timeline bar will disappear.


The screenshot shows a timeline from 0 to 23. A red bar is highlighted from 08 to 19. A green bar is shown erasing the red bar from 14 to 18. Below the timeline, the Start Time is set to 14:00 and the End Time is set to 19:00. The 'Add' and 'Delete' buttons are visible. The 'Delete' button is highlighted with a green box.

The screenshot shows a timeline from 0 to 23. A red bar is highlighted from 08 to 19. A green bar is shown erasing the red bar from 14 to 18. Below the timeline, the Start Time is set to 14:00 and the End Time is set to 19:00. The 'Add' and 'Delete' buttons are visible.

## Set up applicable period of time



For repeat frequencies, you can set up the applicable date and period of time for the time frame.

- Specify the start date and time in the **Start** field. A calendar date selector will appear when you click on the drop-down list of **date**. Click  or  to select the month, then pick a desired day in the calendar.
- Specify the end date and time in the **End** field if you have an end time for applying this time frame. If you do not have a terminating time for this time frame, select **Never Stop**.



## Set up repeat time interval

The repeat time intervals is "every N day(s)" as shown below. Repeat every 1 day means the time frame would apply for every day within the period of time.

Repeat every    Day(s)

## Repeat Frequency: Weekly Setting (Day-based)

To set up Weekly (Day-based) repeat frequency, please configure the following items: Daily time segments, applicable days within a week, applicable period of time, and repeat time interval.

**Time Frame**

Time Frame Name  Load Template Save as Template Save

Repeat Frequency **Weekly Setting (Day-based)**

**Weekly Setting (Day-based)**

Set time segments in a 24-hour day. Multiple segments are allowed.

**Daily timeline control bar (24h)**

Start Time 00:00 End Time 00:00 Add Delete

Repeat on ☐ Sunday ☐ Monday ☐ Tuesday ☐ Wednesday ☐ Thursday ☐ Friday ☐ Saturday

Range:

Start 2010/ 1/28 End 2010/ 1/28 Never Stop

Repeat every 1 Week(s)

**Daily Time segments**  
\*You can drag more than one time segment per day.

**Applicable days within a week**

**Applicable period of time**

**Repeat time interval**

### Set up daily time segments

Please refer to page 74 for detailed instructions.

### Set up applicable days within a week

For repeat frequency--"Weekly (day based)", you can apply the time segments only on selected days of the week.

Repeat on ☐ Sunday ☐ Monday ☐ Tuesday ☐ Wednesday ☐ Thursday ☐ Friday ☐ Saturday

### Set up applicable period of time

Please refer to page 76 for detailed instructions.

### Set up repeat time interval

The repeat time intervals is "every N week(s)" as shown below. Repeat every 1 week means the time frame would apply for every week within the period of time.

Repeat every 1 Week(s)



## Repeat Frequency: Weekly Setting (Periods in a week)

To set up Weekly (Periods in a week) repeat frequency, please configure the following items: Time segments within a week, applicable period of time, and repeat time interval.

The screenshot shows the 'Time Frame' configuration window. It includes fields for 'Time Frame Name', 'Repeat Frequency' (set to 'Weekly Setting (Periods in a week)'), and buttons for 'Load Template', 'Save as Template', and 'Save'. Below these, the 'Weekly Setting (Periods in a week)' section contains a weekly timeline control bar (labeled 'Weekly timeline control bar') and a daily timeline control bar (labeled 'Daily timeline control bar (24hr)'). The daily bar is active, showing a 24-hour grid. Below the timeline bars are 'Start Time' and 'End Time' fields, both set to 'Sunday' with time values of '00:00'. To the right of these fields are 'Add' and 'Delete' buttons. A 'Range' section below has 'Start' and 'End' date pickers (both set to '2010/ 1/28') and a 'Never Stop' radio button. At the bottom, a 'Repeat every' field is set to '1' with a unit dropdown set to 'Week(s)'. Blue annotations with arrows point to the weekly timeline bar, the daily timeline bar, the 'Range' section, and the 'Repeat every' field.

**Time segments within a week**  
\*You can drag more than one time segment per week.

**Applicable period of time**

**Repeat time interval**

## Set up time segments within a week

You can specify several time segments within a week. The **weekly timeline control bar** represents the 7 days of a week, and the **daily timeline control bar** represents the 24 hours in a day. The daily timeline control bar is only valid when one of the days on the weekly timeline control bar has been selected.

There are two ways to set up time segments: one is to use the computer mouse to draw the timeline control bars; the other is to fill in the precise start and end time value in the corresponding fields.

### Add time segments: Choose either step 1 or step 2 to set up

1. Use the mouse to drag the timeline bars:
  - a. Click on a day on the **weekly timeline control bar**. The selected bar will turn green.
  - b. **Left-click** the **daily timeline control bar** and drag the mouse.
  - c. The corresponding time segment will also appear in the Start Time and End Time fields. Click **Add**, then the red timeline bars representing new time segments will appear as shown below. You can drag multiple time segments within a day and a week.

In the following illustration, the yellow arrows show the dragging direction of the mouse. You can drag from left to right or the opposite.

This illustration shows the 'Time Frame' window with annotations 'a', 'b', and 'c'. Annotation 'a' points to 'Mon' on the weekly timeline bar, which is highlighted in green. Annotation 'b' points to the daily timeline bar, where a red segment is being dragged from hour 8 to hour 19. A yellow arrow indicates the dragging direction. Annotation 'c' points to the 'Start Time' and 'End Time' fields, which now show 'Monday' and '08:00' and 'Monday' and '19:00' respectively. A hand icon is shown clicking the 'Add' button.

2. Fill in a precise Start Time and End Time:

- Directly select a day and enter the value in the Start Time and End Time fields, then click **Add**.
- The corresponding red timeline bars will automatically appear as shown below.

The following is an example of an extended time segment from Mon. 8:00 to Fri. 19:00.

The interface shows a calendar with days Sun, Mon, Tue, Wed, Thu, Fri, Sat. A red bar highlights the segment from Monday 8:00 to Friday 19:00. Below the calendar, a form labeled 'a' contains 'Start Time' (Monday, 08:00) and 'End Time' (Friday, 19:00) fields. A red bar labeled 'b' is shown on the timeline below the form. 'Add' and 'Delete' buttons are at the bottom right.

**Delete time segments:** Please refer to page 75 for detailed instructions.

### Set up applicable period of time

Please refer to page 70 for detailed instructions.

### Set up repeat time interval

Please refer to page 77 for detailed instructions.

## Repeat Frequency: Monthly Setting (Day-based)

To set up Monthly (Day-based) repeat frequency, please configure the following items: Daily time segments, applicable date(s) of a month/ day(s) of a week, applicable period of time, and repeat time interval.

The screenshot shows the 'Time Frame' configuration window. It includes a 'Time Frame Name' field, 'Load Template', 'Save as Template', and 'Save' buttons. The 'Repeat Frequency' is set to 'Monthly Setting (Day-based)'. Below this, the 'Monthly Setting (Day-based)' section contains a 'Timeline control bar (24hr)' with a 24-hour grid. To the right of this grid is the annotation 'Daily time segments \*You can drag more than one time segment per day.' Below the timeline is a 'Repeat on' section with a 'Date (of a month)' dropdown, a calendar for January 2010, and a 'Repeat on the following date(s) of a month:' text box. To the right of this section is the annotation 'Applicable date(s) of a month/ day(s) of a week'. Below the calendar is a 'Range' section with 'Start' and 'End' date pickers (set to 2010/ 1/28) and a 'Never Stop' radio button. To the right of this section is the annotation 'Applicable period of time'. At the bottom, the 'Repeat every' section is set to '1 Month(s)', with the annotation 'Repeat time interval' pointing to it.

**Time Frame**

Time Frame Name  Load Template Save as Template Save

Repeat Frequency **Monthly Setting (Day-based)**

**Monthly Setting (Day-based)**

Set time segments in a 24-hour day. Multiple segments are allowed.

**Timeline control bar (24hr)**

Start Time 00 00 End Time 00 00 Add Delete

Repeat on Date (of a month)

January 2010 Repeat on the following date(s) of a month:

Sun	Mon	Tue	Wed	Thu	Fri	Sat
					1	2
3	4	5	6	7	8	9
10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30
31						

Delete

Range:

Start 2010/ 1/28 End 2010/ 1/28 Never Stop

Repeat every 1 Month(s)

**Daily time segments**  
\*You can drag more than one time segment per day.

**Applicable date(s) of a month/ day(s) of a week**

**Applicable period of time**

**Repeat time interval**

### Set up daily time segments

Please refer to page 74 for detailed instructions.

### Set up applicable date(s) of a month/ day(s) of a week

For repeat frequency--"monthly (day-based)", you can apply the time segments only on selected days of a month. There are two types of repeat frequencies: Date(s) of a month and Day(s) of a week.

**Repeat by date(s) of a month:**

Select date(s) from the calendar, and it will be displayed on the right blank as shown below. The following example refers to the 1<sup>st</sup> ~ 5<sup>th</sup> day of a month.

Repeat on Date (of a month)

January 2010

Sun	Mon	Tue	Wed	Thu	Fri	Sat
					1	2
3	4	5	6	7	8	9
10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30
31						

Repeat on the following date(s) of a month:

01  
02  
03  
04  
05

Delete

**Repeat by day(s) of a week:**

Select day(s) from the calendar, and it will be displayed on the right blank as shown below. The following example refers to the 1<sup>st</sup> ~ 5<sup>th</sup> Friday of a month.

Repeat on Day (of a week)

January 2010

Sun	Mon	Tue	Wed	Thu	Fri	Sat
					1	2
3	4	5	6	7	8	9
10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30
31						

Repeat on the following day(s) of a month:

1st Friday  
2nd Friday  
3rd Friday  
4th Friday  
5th Friday

Delete

**Set up applicable period of time**

Please refer to page 76 for detailed instructions.

**Set up repeat time interval**

The repeat time intervals is "every N month(s)" as shown below. Repeat every 1 month means the time frame would apply for every month within the period of time.

Repeat every  Month(s)

## Repeat Frequency: Yearly Setting (Day-based)

To set up Yearly (Day-based) repeat frequency, please configure the following items: Daily time segments, applicable date(s) of a year/ day(s) of a week, applicable period of time, and repeat time interval.

The screenshot shows the 'Time Frame' configuration window. It includes a 'Time Frame Name' field, 'Load Template', 'Save as Template', and 'Save' buttons. The 'Repeat Frequency' is set to 'Yearly Setting (Day-based)'. Below this, the 'Yearly Setting (Day-based)' section contains a 'Timeline control bar (24hr)' with a 24-hour grid. To the right of this grid is the annotation 'Daily time segments' with a note: '\*You can drag more than one time segment per day.' Below the timeline is a 'Repeat on' section with a 'Date (of a year)' dropdown, a month/year selector (January 2010), and a calendar grid. To the right of the calendar is the annotation 'Applicable date(s) of a year/ day(s) of a week'. Below the calendar is a 'Range' section with 'Start' and 'End' date pickers (2010/ 1/28) and a 'Never Stop' option. To the right of this is the annotation 'Applicable period of time'. At the bottom is a 'Repeat every' section with a value of '1' and a unit of 'Year(s)', with the annotation 'Repeat time interval' pointing to it.

**Time Frame**

Time Frame Name  Load Template Save as Template Save

Repeat Frequency Yearly Setting (Day-based)

**Yearly Setting (Day-based)**

Set time segments in a 24-hour day. Multiple segments are allowed.

**Timeline control bar (24hr)**

Start Time 00 00 End Time 00 00 Add Delete

Repeat on Date (of a year)

January 2010 Repeat on the following date(s) of a year:

Sun	Mon	Tue	Wed	Thu	Fri	Sat
3	4	5	6	7	1	2
10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30
31						

Delete

Range:

Start 2010/ 1/28 End 2010/ 1/28 Never Stop

Repeat every 1 Year(s)

**Daily time segments**  
\*You can drag more than one time segment per day.

**Applicable date(s) of a year/ day(s) of a week**

**Applicable period of time**

**Repeat time interval**

### Set up daily time segments

Please refer to page 74 for detailed instructions.

### Set up applicable date(s) of a month/ day(s) of a week

For repeat frequency--"yearly (day-based)", you can apply the time segments only on selected days of a year. There are two types of repeat frequencies: Date(s) of a year and Day(s) of a week.

**Repeat by date(s) of a year:**

Select date(s) from the calendar, and it will be displayed on the right blank as shown below. The following example refers to the 1<sup>st</sup> ~ 5<sup>th</sup> day of a year.

Repeat on Date (of a year)

January 2010

Sun	Mon	Tue	Wed	Thu	Fri	Sat
					1	2
3	4	5	6	7	8	9
10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30
31						

Repeat on the following date(s) of a year:

01/01  
01/02  
01/03  
01/04  
01/05

Delete

**Repeat by day(s) of a week:**

Select day(s) from the calendar, and it will be displayed on the right blank as shown below. The following example refers to the January 1<sup>st</sup> ~ 5<sup>th</sup> Friday of a year.

Repeat on Day (of a week)

January 2010

Sun	Mon	Tue	Wed	Thu	Fri	Sat
					1	2
3	4	5	6	7	8	9
10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30
31						

Repeat on the following day(s) of a year:

January 1st Friday  
January 2nd Friday  
January 3rd Friday  
January 4th Friday  
January 5th Friday

Delete

**Set up applicable period of time**

Please refer to page 76 for detailed instructions.

**Set up repeat time interval**

The repeat time intervals is "every N year(s)" as shown below. Repeat every 1 year means the time frame would apply for every year within the period of time.


Repeat every  Year(s)

## How to Manually Begin /Stop Recording

By default, all devices are assigned to the default recording storage and default recording schedule. Therefore, once you insert a device onto the station, the ST7501 Server will begin to record live video according to the default recording schedule. Please refer to **How to Edit Recording Schedules** on page 66.

However, if you have changed the default schedule, you can manually click **Manually Begin Recording** to enable a device without setting up a recording schedule. Please follow the instructions below to manually begin recording.

Select the device from the device tree under Default Group, then click **Edit > Manually Begin Recording** on the menu bar (or **right-click** the device and select **Manually Begin Recording**). The string on the menu bar will turn into **Manually Stop Recording** as shown below and the ST7501 Server will start to record video from the target camera. Please note that its priority will be higher than the recording schedule, so it will continue unless you click **Manually Stop Recording**. After you click **Manually Stop Recording**, the device will then follow the preset recording schedule.






## How to Edit Scheduled Backup Settings

ST7501 LiveClient supports scheduled backup which allows the user to back up the recorded data in another disk.

Please follow the steps below to enable scheduled backup settings:


- a. Click **Configuration > Station Settings > Scheduled Backup Settings** on the menu bar (or **right-click** the station and select **Station Settings > Scheduled Backup Settings**).



- b. The **Scheduled backup settings** window will pop up.

### Select Backup Source

- c. Check **Enable schedule backup**.
- d. Select the data source you want to backup. If you check **Selected cameras**, you can click >> or << to choose the data source that you want to backup.




## Setup Backup Schedule

- f. Fill in a desired time and click >> to add the backup time. Please note that the backup time interval must not less than 1 hour. For example, 23:40 and 00:15 are not allowed to exist simultaneously.

In the following example, the server will backup the recorded data at 12:00 PM and 23:00 PM everyday once you save the settings.




The following diagram shows the backup schedule and backup data:



## Select Backup Target

- g. Click **Browse...** to select a path (local path or network storage) to store the backup data. Please note that the disk for backup data should be different from the original recording path, or a warning message will pop up as shown below. For more information about how to set up recording path, please refer to page 63.



- h. Select a maximum size for backup folder. The server will divide backup data into the following size: VCD (650M), DVD (4.7G), Customize, or Unlimited size according to your choice.
- i. Check **Delete old backups if space is insufficient** if you want to do cyclic backup due to the limited size of the hard disk.


## Other Options

- j. If you only want to backup the recorded data of events, select **Backup only events** and fill in the pre- and post-event time.

## How to Configure Station Server Settings

ST7501 LiveClient supports Server Settings including DDNS Settings, Network Storage Settings, and SMTP Settings.


Select the station from the device tree and click **Configuration > Station Settings > Server Settings** to open the page (or **right-click** the station and select **Station Settings > Server Settings**).



### DDNS Settings

Since the public IP of ST7501 Server may be a dynamic IP address, DDNS service will give it a fixed domain name.


Select a DDNS provider from the provider drop-down list. VIVOTEK offers [2bthere.net](http://2bthere.net) (Safe100.net), a free dynamic domain name service, to VIVOTEK customers. Please refer to the user's manual of VIVOTEK's network camera for detailed DDNS settings.




## Network Storage Settings

The ST7501 Server allows user to set up network storage path(s) for recorded files. Please follow the steps below to add a new network storage path.

- a. Click **Add** to open the Network Host Window.
- b. Fill in the related information for the network host. Then click **OK** to save the new settings.



- c. If you want to add more network host(s), please repeat step a. b.






## SMTP Settings

ST7501 Server allows user to set up SMTP Server to send mail alert when event triggers. For more information about how to set up event management, please refer to page 54.

Please follow the steps below to configure the SMTP Server:


- Click **Add** to open the SMTP Settings page.
- Enter the related information of your mail server. If your SMTP server requires a secure connection (SSL), check **Use SSL**.
- Click **OK** to enable the settings.
- Then the new information will appear on the SMTP Settings window as shown below.



If you have more than one SMTP server, you can click to arrange the priority.



## Relay Settings

The ST7501 server can be set as a sub-station of VAST, the VIVOTEK professional central management software, so as to construct a hierarchical management architecture. Following is an illustration for two-level hierarchical architecture:



For VAST to set ST7501 as a sub-station, please follow the instruction below to enable the Relay Settings first.


- Click **Configuration > Station Settings > Relay Settings** on the menu bar (or **right-click** the station on the hierarchical management tree and select **Station Settings > Relay Settings**).
- The **Relay Settings** window will pop up. Check **Allow Relay Connection** and enter a **Password**. Then click **OK** to enable the settings.



## How to Use the Talk Panel

ST7501 LiveClient supports the two way audio function which allows the user to communicate with people around the network camera. Please enable the two way audio function on the camera side.


The following is an illustration of the two way audio function:



## Add a Camera to the Talk Panel


■ There are several ways to add a Network Camera to the Talk Panel:

Drag-and-drop a camera from the video cell or from the device tree to the talk panel as shown below. You can also **right-click** the target camera or the video cell, then click **Send to Talk Panel** on the pop-up menu.






- An icon with the camera name will be displayed in the Talk Panel.




- Please note that you cannot **Talk** and **Play Sound** at the same time.
- When you are talking or playing sound, you cannot add other cameras to the Talk Panel. If you want to add more cameras to the Talk Panel, please **Stop Talking** and **Stop Playing** first.



## Remove a Camera from the Talk Panel

### ■ Remove a camera

Drag a camera from the Talk Panel and drop to the hierarchical management tree window as shown below. The camera icon will disappear.




### ■ Remove all cameras

Click  , all cameras in the Talk Panel will be removed.


## How to Configure E-map Settings


ST7501 LiveClient supports intuitive E-map function which allows users to upload E-maps for overall devices management.

Click **System > E-map** to open E-map Settings Page:



## Upload an E-map

Click  to search for E-map(s) to upload.




The uploaded E-maps will be listed under the E-map list tree.



*If the uploading procedure fails, please compress the image size of your map (< 5MB) and try again.*


## User Interface of E-map Settings Page (View Mode)

- **Double-click** an E-map on the tree, it will be displayed on the E-map window as shown below. There are two operation modes of E-map settings page: "View Mode" and "Edit Mode". The following is the "View Mode" illustration.




A. Menu bar    B. Quick access bar    C. E-map list tree    D. E-map window    E. Status panel

- **Right-click** the E-map, then you can **edit**, **rename**, or **delete** the E-map.










- **Right-click** an E-map on the tree and click **Edit** or click  on the Quick Access Bar, it will switch to edit mode.



### Quick Access Bar




Icon	Function	Description
	<b>Zoom in</b>	Zoom in the E-map
	<b>Zoom out</b>	Zoom out the E-map
	<b>Default size</b>	Adjust the E-map to default size
	<b>Upload</b>	Upload E-map to the login station
	<b>View Mode</b>	Click to switch to view mode
	<b>Full Screen</b>	Extend the E-map settings page to full screen
	<b>Save</b>	Save E-map settings

### Status Panel

User Name: STAdmin  
 Station Name: VVK\_Station1  
 Login Time: 2010-08-23 09:42:46  
 Current Time: 2010-08-23 12:00:48


User Name  
 Station Name  
 Login Time (yyyy-mm-dd hh:mm:ss)  
 Current Time (yyyy-mm-dd hh:mm:ss)

## User Interface of E-map Settings Page (Edit Mode)



- A. Menu bar      B. Quick access bar      C. E-map list tree      D. Device tree  
E. Map preview      F. E-map window      G. Status panel

■ **Right-click** the E-map, you can **download**, **rename**, or **delete** the E-map.



## Device Management

Please follow the steps below to edit an uploaded E-map.

- Double-click** the E-map you want to edit, it will be displayed on the E-map window.
- Use Quick Access Bar to adjust the size of the E-map. In edit mode, you can also use your mouse to drag the position of the E-map and zoom in or zoom out the E-map.
- Drag-and-drop** the connected devices to the E-map according to your deployment.



- Right-click** the device icon on E-map, you can **rotate** the direction or **delete** the device. The device can be rotated in 8 directions as shown below.



- You can also drag the DI/DO device under the linked device onto the E-map. If you want to change the status of the **DO** device, **double click** the DO icon on E-map.

For more information about DI/DO settings, please refer to Association Management on page 52.

 / 	Digital input on / off
 / 	Digital output on / off

- Click  on the Quick Access Bar to save the new settings.



*The red frame twinkling around the device means there is event trigger(s) going on. Meanwhile, a live view dialog will pop up beside the model.*






## Live View Dialog Settings

Click **Configuration** > **E-map Settings** to open the E-map Settings dialog, then you can choose to **Open Live View Dialog** or to **Send to Single View** when you double-click the device deployed on the E-map.


### Open Live View Dialog

Select **Open Live View Dialog**: When you **double-click** the device icon on the E-map or when an event triggers, a live view dialog will pop up beside it. It is the default setting in E-map Settings window.




### Send to Single View

Select **Send to Single View**: When you **double-click** the device icon on the E-map, it will open a single view on the ST7501 LiveClient.




If you have set up dual monitor, it will be automatically sent a single view to the second monitor.


**Monitor 1**




**Monitor 2**






The live view dialog also supports **click on image**, **PTZ**, and **e-PTZ** as long as the linked device supports and enables those functions. To enable those function on E-map, please check the item "Enable click on image" on the menu bar of LiveClient as shown below. Then an icon  will appear in the live view dialog for you to control the cameras.



## E-map Link

After completing device deployment on your E-map, you can link an E-map to another E-map. Please follow the steps below to configure E-map link:

a. Select a map you want to edit and enter **Edit Mode**.



b. **Drag-and-drop** another E-map onto current E-map. A blue frame will appear as shown below. For example: Link Map1 to Map2 by dragging Map2 onto Map1




c. Use  to move the position of the blue frame.

d. **Right-click** the blue frame to **Resize** or **Delete** it.



Click **Resize**, some nodes will appear around the blue frame. Then You can drag the nodes to move the position, rotate the direction, adjust the size, and change the shape.




resize




rotate the direction  
change the shape




move the position

e. Click  on the Quick Access Bar to save the new settings.

f. If you want to set additional map links, please repeat steps a. ~ e.  
For example: Link Map2 to Map3 by dargging Map3 onto Map2




g. Click  on the Quick Access Bar to save the new settings.


- h. Test the web links. Click  on the Quick Access Bar to switch to view mode.  
**Double-click** the blue frame on Map1, it will automatically switch to map2. Then **double-click** the blue frame on Map2, it will automatically switch to map3.



Map 1




Map 2



Map 3

## How to Configure Client Settings


In Client Settings, you can configure Snapshot Settings, Recording Settings, View Settings, General Settings, Joystick Settings, and Proxy Settings.



### Snapshot Settings


Please follow the steps below to configure snapshot settings:

- Click **Configuration > Client Settings > Snapshot Settings** on the menu bar to open the **Snapshot Settings** window.
- Select a picture format for snapshots (**BMP** or **JPEG**). If you select **JPEG** format, you can adjust the recompression quality (from 1 to 100). Note that a higher value would generate higher picture quality but lower compression rate.
- Enter a filename prefix for the snapshots.
- The default storage path for snapshots is C:\Program Files\VIVOTEK Inc\ST7501\Client\LiveClient\Snapshot. If you want to change the storage path, click **Browse** ... to select another folder.




*The recompression quality is only enabled in MPEG-4 streaming. If your stream source is MJPEG, the system will directly save the JPEG image without recompression.*

- If you check **Generate a file name automatically**, ST7501 will directly save snapshots with the following filename format to the storage folder.







If you uncheck **Generate a file name automatically**, the **Save file** dialog box will pop up when you take a snapshot. The file name prefix will automatically be displayed in the Save File dialog box.



## Take a Snapshot

Please follow the steps below to take a snapshot of the live video stream:

- Select the video cell of which you want to take a snapshot.
- Click **Snapshot**  on the quick access bar, or **right-click** the video cell and select **Others > Snapshot** from the popup menu. You also can click **Edit > Snapshot** to take a snapshot.



- The snapshots will be found in the preset storage folder on your local computer.

## Recording Settings


The ST7501 Server allows you to record the live video in EXE, 3GP, or AVI format to your storage folder.

### Type 1: Record to EXE

Record video as an EXE file. The EXE is not only a media file but also a built-in media player. When user execute the EXE, the media file will be played automatically. There is no need to install any other program. For more information about how to use the EXE player, please refer to page 109.

Please follow the steps below to configure EXE record settings:

- Click **Configuration > Client Settings > Recording Settings** on the menu bar to open the **Recording Settings** window.
- Select **EXE** as the Record Type.
- The default storage path is C:\Program Files\VIVOTEK Inc\ST7501\Client\LiveClient\Record. If you want to change the storage path, click **Browse ...** to select another folder.
- Select the Length of each file-- **Maximum Size** (10~2000MB) or **Maximum Time Interval** (1~150 min).



- Click **OK** to enable the settings.


### Type 2: Record to 3GP

Record video as a 3GP file. 3GP file is a standard MP4 format compatible with players such as VLC, QuickTime, or Real players. Choose this type if you has already installed one of these players.

Please follow the steps below to configure 3GP record settings:

- Click **Configuration > Client Settings > Recording Settings** on the menu bar to open the **Recording Settings** window.
- Select **3GP** as the Record Type.
- The default storage path is C:\Program Files\VIVOTEK Inc\ST7501\Client\LiveClient\Record. If you want to change the storage path, click **Browse ...** to select another folder.
- Select the Length of each file-- **Maximum Size** (1~2000MB) or **Maximum Time Interval** (1~150 min).






- e. If you check "Record with only standard codec", the video from old models (VIVOTEK 6000-series products) using G7221/G729A/H.263 codec will not be recorded.
- f. Click **OK** to enable the settings.

### Type 3: Record to AVI

Record video as an AVI file, which uses the popular codecs pre-installed in the Windows OS. Please note that the speed may be slower due to the need of decoding the video/audio and re-encoding both into a compatible codec.


Please follow the steps below to configure AVI record settings:

- Click **Configuration > Client Settings > Recording Settings** on the menu bar to open the **Recording Settings** window.
- Select **AVI** as the Record Type.
- The default storage path is C:\Program Files\VIVOTEK Inc\ST7501\Client\LiveClient\Record. If you want to change the storage path, click **Browse** ... to select another folder.
- Select the Length of each file-- **Maximum Size** (1~2000MB) or **Maximum Time Interval** (1~150 min).




*Due to the AVI file has a limitation on the maximum file size of 2G bytes, if the setting "time length" generates data larger than 2G bytes, several files will be created.*

- e. Select the frame rate/ per second.
- f. To modify the video compression settings, click **Video Compression Setting** to open the AVI Video Compression Setting window. Select the desired **video compression algorithm**, **compression quality**, **key frame intervals**, and **data rate** in the corresponding fields.



*If you do not choose to compress the video, the generated AVI file will be very large.*


- To modify the settings of the compression algorithm: Click **Configure**, then a dialog box will pop up for you to modify the settings. The dialog box will be different according to the compressor you select.



- To read the information of a compression algorithm (its version for instance): Click **About**, and a dialog box will pop up showing the related information. The dialog box will be different according to the compressor you select.





- g. To modify the audio compression settings, click **Audio Compression Setting** to open the AVI Audio Compression Setting window. Select the desired **audio quality**, **format**, and **attributes** in the corresponding fields.




## Record an EXE/3GP/AVI File



Please follow the steps below to record an EXE/3GP/AVI file of a live video stream:


- Select a video cell or a device from the hierarchical management tree which you want to record to media file.
- Click **Record to EXE/3GP/AVI**  on the quick access bar, or **right-click** the video cell and click **Record to EXE/3GP/AVI**. You can also click **Edit > Record to EXE/3GP/AVI** on the menu bar. (The UI string will change according to your Recording Settings.)






- For recording a high-resolution video (1600 x 1200) in AVI type, a dialog box will pop up as shown below to remind you that the CPU loading will increase. Click **OK** to continue the process.




- The icon  will then change to **Recording EXE/3GP/AVI** , and a red text string (**EXE/3GP/AVI**) will appear at the bottom right of the video cell. Note that only one video channel can be recorded at a time.



- When you want to terminate the AVI Recording, click the icon  on the Quick Access Bar. The export process will then terminate and the button will change from  to . The recorded media files will be found in the preset storage folder on your local computer as shown below.

Below is the file name format for AVI files:




## Built-in Media Player--EXE

Shown below is the icon of EXE. Double-click it, the recorded video will be played automatically as shown below.



20091118\_112743.exe  
MediaPlayer Application

Video Title



Control Buttons

Timeline Slider

Status Panel

Total length of the histogram

The playing rate can be 1/8, 1/4, 1/2, 1X, 2X, 4X, 8X, 16X, 32X, and 64X.

Current time of the video clip

Icon	Function	Description
	Pause	Pause playback of the focused video clip
	Play	Start playback of the focused video clip
	Stop	Stop playback of the focused video clip
	Next Frame	Go to the next video frame of the focused video clip
	Slow Down	Slow down the playback rate
	Speed Up	Speed up the playback rate



The function menu of the built-in media player are displayed as shown below:

File	Edit	View	Edit	View	View
Open 3GP File ...			Snapshot (BMP)		Full Screen
Save as EXE ...			Snapshot (JPEG)		
Save as 3GP File ...			Convert to AVI		
Print					
Exit					

- The built-in player is able to playback 3GP and EXE files.
- The built-in player is able to save 3GP files as EXE files.
- The built-in player is able to save EXE files as 3GP files.
- The built-in player is able to convert EXE and 3GP files into AVI files.
- The built-in player also supports snapshot and print functions.



Below are special notices related to video recording with the fisheye cameras:

- For recorded videos from the fisheye cameras, only the built-in Media Player can playback the Regional or Panoramic views. If you access the recorded videos using other playback software, you will end up with the oval-shape Original view.
- When recording videos from fisheye cameras, Regional and Panoramic views can only be preserved in the EXE and 3GP format. If you save the de-warped views, i.e., Regional and Panoramic, as AVIs, only the oval-shape Original view will be preserved.
- Currently the video playback on the Emap window displays the Original view only.
- To display a Regional or Panoramic view, right-click on the Media Player window.



## View Settings

This section allows you to set the display mode of a video cell, including **Display Location**, **Date and time Format**, **Video Display Mode**, and **Font Settings**. When you change the settings, the sample window will change accordingly for you to preview the settings.

**View Settings**

**Display Location**

Display Area 1: Camera Name

Display Area 2: Camera Date & Time

Display Area 3: Video Title

Display Area 4: No display

**Date and Time Format**

☒ Same as Local Computer

☐ Specify

Date Format: YYYY/MM/DD

Time Format: Default Time Format

**Font Settings**

Font: System

Color:

Size: 10

**Video Display Mode**

☐ Keep the aspect ratio

☒ Show motion windows when triggered

OK Cancel

### Display Location

**Display Location**

Display Area 1: Camera Name

Display Area 2: Camera Date & Time

Display Area 3: Video Title

Display Area 4: No display

Display Area 1: Camera Name

Display Area 2: 2010/1/29 PM 02:07:01

Display Area 3: Video Title

Display Area 4:

As the illustration shows, there are 4 display areas for you to input information about the live video. Each drop-down list includes 6 options for you to select: **No display**, **Camera Name**, **Video Title**, **Camera Date**, **Camera Time**, and **Camera DateTime**.

## Date and Time Format

- Same as local computer: Select this option and then the date and time format will synchronize with the local computer.

- Specify: Select a desired format for the date and time from the drop-down list.

**Date format:** Select YYYY/MM/DD or MM/DD/YY.

**Time format:** Select the default time format (synchronize with the local computer), 12h AM/PM, or 24h.

## Video Display Mode

- Keep the aspect ratio: In the default settings, the size of the video window will change according to the layout of the live view window you choose. However, the frame size may be distorted. If you select **Keep the aspect ratio**, the video window will be adjusted to the same frame size as the preview window. This function is disabled as default.
- Show motion window when triggered: If you select this option, the red frame of the motion detection window will appear in the video window when motion is triggered. This function is enabled as default.



For detailed information about how to set up the layout of the live view window, please refer to **How to Change Video Viewing Mode** on page 40.

## Font Settings

This function allows you to change the font on the video cell.

- Font: Automatically lists all fonts installed on your operating system. Select the desired type.
- Color: Select a desired font color (white, red, green, blue).
- Size: Select a desired font size (8, 10, 12, 14).




## General Settings

This section allows you to configure the **System Settings** and **Rotation Settings**.

### System Settings

- **Auto login after logging in to operating system:** If you check this option, ST7501 LiveClient will automatically login after you login to Windows without entering the user name and password. The default setting of this function is disabled.
- **Automatically display in full screen after login:** If you check this option, the video cells will be displayed in full screen without showing the menu bar or the control panels.
- **Auto add newly-inserted camera to video cell:** If you check this option, ST7501 LiveClient will automatically add the newly-inserted device to a video cell. This function is enabled as default.
- **Retrieve RTSP streaming on specific port:** The default port for RTSP streaming is 554. If you want to change this port, please check this item and fill in a desired port.



### Event Settings

- **Enable live event notification:** Select this option to activate real-time event notification. For example: the event notification of DI/O status on the hierarchical management tree, the event list in the event window, motion detection windows in video window, or the event notification on E-map settings page, etc. This function is enabled as default.
- **Enable alert sound(s):** If you enable this option, you will hear alert sound on the client side when the event is triggered..
- **Event window mode:** Select **Fixed** or **Popup** mode for the event window. For more information about event window, please refer to page 18.

### Rotation Settings

- **Enable rotation after login:** If you check this option, the video cells will start to rotate after you login to the ST7501 LiveClient. The default setting of this function is disabled.
- **Rotate the page every**  **second(s):** Fill in a desire interval time for video page rotation. The maximum value is 99 seconds. The default value is set at 6 seconds.

For detailed information about how to set up the layout of the monitoring window and rotation functions, please refer to **How to Change Video Viewing Mode** on page 40.

## Display Settings

- Enable **auto stream size**: The Auto Stream Size feature dynamically adjusts the stream sizes of video feeds in order to reduce CPU load and bandwidth consumption. Due to the limitations on the physical dimensions of monitors, effectiveness of visual stimulus, and the operators' regions of interest, streaming large-size videos at all times will be a waste of bandwidth and system computing power. It is often the case that CIF and VGA size videos are sufficient for the operators of a surveillance software.

When enabled, your ST station automatically requests smaller-size streams as video feeds (any from streams #1 ~ #4) from the network cameras. For example, the frame size of video stream #4 will be reduced to 320x240 (CIF). Depending on the actual size of view cells on the ST monitoring screen, the ST server automatically requests different video streams.

When the size of view cells is manually expanded, an ST7501 server requests a different stream. This is called **Stream Jump**. Shown below are the details of the corresponding stream swaps.

View cell size	Stream jump to...
4:3 resolutions	
<= 320x240	stream #4
> 320x240 or 640x480	stream #1
16:9 resolutions	
<= 384x216	stream #4
> 384x216 or 640x360	stream #1
1:1 (fisheye cameras)	
<= 384x384	stream #4
> 384x384 or 640x640	stream #1

Facts about Auto Stream Size:

- The LiveClient utility automatically adjust stream selection according to the size of view cells, no user's configuration is required.
  - The frame size of stream #1 is user-configurable. The ST7501 server only resizes stream #4.
  - If a user disables the Auto Stream Size function late, the frame size of stream #4 will not be restored to the previous configuration.
  - Stream jump takes place on the display of all connected cameras once the function is enabled.
  - The Auto Stream Size function does not apply to the Matrix view.
  - If users configured a region of interest before the Auto Stream Size function is applied, e.g., via the ePTZ control, the view cell might display a different live view.
- Enable de-interlace function: Select this option if your connected device does not support de-interlace function. For example: VS7100.

## Joystick Settings



This section explains how to remote control connected network devices with a USB joystick. It's easy to install and configure via the USB interface.

### Enable Joystick

Connect the USB plug of the joystick to a USB port on your computer. Supported by the plug-in in the main page (Microsoft's DirectX), once the plug-in in the main page is loaded, it will automatically detect if there is any joystick on the computer. The joystick should work properly without installing any other driver or software.

Then you can begin to configure the joystick settings of linked devices. Please follow the instruction below to enable joystick settings.

- Click **Configuration > Client Settings > Joystick Settings** on the menu bar to open the **Joystick Settings** window. If your joystick is working properly, it will be displayed on the drop-down list.
- Select the joystick you want to configure. Check **Enable Joystick**, then click **Configure Buttons** to open Buttons configuration window.




## Buttons Configuration

In Buttons Configuration window, the left column shows the actions you can assign, and the right column shows the functional buttons and assigned actions. The number of buttons may differ from different joysticks.


Please follow the steps below to configure your joystick buttons:

- a. Choosing one of the actions and click **Assign** will pop up a dialog. Then you can assign this action to a button by pressing the joystick button or select it from the drop-down list.


For example: Assign **Home** (move to home position) to Button 1.




- b. Click **OK** to confirm the configuration.




- c. The Assigned Action will appear beside Button 1 in the right column as shown in the following diagram. Note that a button can only be assigned with an action. If you want to modify the settings, select the action on the list and click **Clear Selected**.




- d. If you want to assign additional actions, repeat step a.~c. When all settings are complete, click **OK** to save the settings or click **Cancel** to discard the settings.




e. Click **OK** to save the settings or click **Cancel** to discard the settings.



- If you want to assign Preset actions to your joystick, the preset locations should be set up in advance.
- If your joystick is not working properly, it may need to be calibrated. Click **Calibrate** to open the Game Controllers window located in the MS Windows control panel and follow the instructions for trouble shooting. For more information, please refer to the MS Windows help files for details.



- The joystick will appear in the Game Controllers list in the Windows Control Panel on your computer. If you want to check out your device, go to the following page: Open Start > Control Panel > Game Controllers.





## PTZ/ E-PTZ Function

In addition to using the PTZ control panel, you may also control the rotation handle of the joystick to remote control a PTZ/ E-PTZ network camera with ease.

**Pan/Tilt:** Move the rotation handle of the joystick; you can pan the camera to the desire position. There will be blue line displaying the moving direction in the center of the video image as the diagram 1 below.

**Zoom in/Zoom out:** Shift the rotation handle clockwise to zoom in the camera on an image or go counterclockwise to zoom out the camera on an image. There will be a circle and four vectors in the center of the video image as the diagram 2, 3 below.



Pan/Tilt

(Move the rotating handle back and forth)



Zoom in

(Turn the rotating handle clockwise)





Zoom out

(Turn the rotating handle counter-clockwise)

## Proxy Settings

In this section, you can enable, modify, or cancel **Proxy Settings** for client if your ST7501 Server is under a proxy. If you change the proxy settings, please fill in the new value next time you login the LiveClient next time.






## How to Search for a Device on the Device Tree

This function allows you to conveniently search for an inserted device, which is useful when many devices have been inserted.

Please follow the steps below to find a device on the camera list:


a. Click the station on the device tree.

b. Click **Edit > Find** on the menu bar (or **right-click** the station and click **Find**).




c. The **Find** window will pop up for you to set your search criteria.


- Find what: Enter a string in the blank. The string can be the full or partial name of the device you want to search for.
- String Options: **Match case** represents that the search results should be identical to the string in lower-case or upper-case letters, the string can be part of a word. **Match whole word** means that the search results should be identical to the string for every character, and that the string should be a complete word or phrase. If you select both options, the search results should conform to all criteria listed above.
- Direction: Select **search up** or **search down**.



d. Click **Find Next**, the searching result will be marked as shown below.





e. If there is nothing found in the camera list, a message will pop up as shown below:




## How to Print a Video Image

There are two ways to print out an image of live video:

1. Select a video cell, then click **Print**  on the quick access bar, or **right-click** the video cell and select **Print** from the popup menu. A Print window will pop up for you to choose the printer.







2. You can also click **Edit > Print** to print out an image from a video.
  - Focus Cell: Print out an image of the target video.
  - All Cells: Print out an image with all video cells in the monitoring window.




## How to Lock ST7501 LiveClient for Security Concerns



If you are away from your computer, for security reasons, we suggest you lock the program. When LiveClient is locked, the user must fill in the correct password to unlock and access the program again.

- To lock LiveClient, click **Unlock**  on the quick access bar or click **System > Lock** on the system menu. The **Unlock**  icon will then turn into **Lock** .
- To unlock LiveClient, fill in the correct password in the popup window.






## How to Log out from the ST7501 Server

To logout from the current server, click **Logout**  on the quick access bar or click **System > Logout** on the menu bar. A confirmation window will pop up. Click **OK** to confirm or **Cancel** to return to the ST7501 LiveClient window.



## How to Exit ST7501 LiveClient

To exit ST7501 LiveClient, click **Exit**  on the quick access bar or click **System > Exit** on the menu bar. A confirmation window will pop up. Click **OK** to confirm or **Cancel** to return to the ST7501 LiveClient window. When you exit the program, your user account will be automatically logged out from the current server.





# ST7501 Playback Configuration

## Activating ST7501 Playback and Logging in to a Server

ST7501 Playback allows you to search and playback recorded media data from ST7501 Server. Once you insert a device into the device tree of ST7501 LiveClient, it will automatically be displayed on the device tree of ST7501 Playback. You can then begin to use ST7501 Playback to view recorded or backup video clips.

After installing the ST7501 Playback program, please follow the steps below to activate ST7501 Playback:



1. Run the **ST7501 Playback** program. If you have already run ST7501 LiveClient, you can also click **System > Launch Playback** to activate ST7501 Playback.
2. A **Login** window will pop up. Fill in the information as shown below:
  - If you want to login to a remote ST7501 Server, enter the **IP address**, **user name**, **password** and **communication port** of the server. Click **Log in** to login the target server or **Cancel** to exit the system.
  - If you want to login to your local host which is running ST7501 Server, check the **Login local station** checkbox, and the local **IP Address** will be displayed automatically. Enter the **User Name**, **Password**, and **Communication Port** of the local server to log in. Click **Login** to log in to the target server or **Cancel** to exit the system.



3. The ST7501 Playback main window will be displayed.




- If your network environment need to set up proxy, click **More >>** to extend the login window, then click **Proxy Setting** to open the dialog. Then enter related information to link to your proxy server.



- Available functions of the ST7501 Playback program will be enabled according to the role of your login account. For more details about the privileges of the user account, please refer to **How to Manage User Accounts** on page 47.

## ST7501 Playback User Interface



- A. Menu bar      B. Quick access bar      C. Query panel (Browsing / Time search / Event search / Log viewer)      D. Status panel      E. Recorded video playback window      F. Playback control panel  
G. Video clips list

### Menu Bar

Menu Bar	
Menu Item	Drop-down Options
System	Lock / Language / Launch LiveClient / Logout / Exit
Edit	Snapshot / Print / Find
View	Backup Status / Exporting Status / Time Search / Event Search / Log Viewer / Full Screen / Minimize
Configuration	Client Settings (Snapshot Settings / Export Settings / View Settings / Proxy Settings / General Settings)
Layout	Change Layout
Help	About

### Status Panel

User Name: STAdmin
Station Name: VVTK_Station1
Login Time: 2010-08-23 09:42:46
Current Time: 2010-08-23 12:00:48

User Name
Station Name
Login Time (yyyy-mm-dd hh:mm:ss)
Current Time (yyyy-mm-dd hh:mm:ss)

## Quick Access Bar



Icon	Function	Description
	Exit	Exit the system
	Logout	Logout from the current station
	Lock	Click to Lock the system for security concerns (  Unlock the system)
	Volume	Adjust the audio volume of the target video (  Mute)
	Snapshot	Capture the picture of the target video
	Print	Print out the picture of the target video
	Remove All Connections	Remove all live videos from the live video monitoring window
	Layout	Change the layout of video monitoring window
	Full Screen	Maximize the live video monitoring window
	Switch Screen	Switch to another screen



*Some buttons will be disabled if the selected device does not support those functions.*

## Recorded Video Playback Window

The "VIVOTEK" logo indicates that no camera has been assigned to the video cell.


The red frame ( ) represents the focused cell.





## Language Selection


ST7501 current supports user interfaces in multiple languages; and language options are available in: English, Deutsch, Español, Français, Italiano, 日本語, Português, 简体中文, and 繁體中文. If you want to select another language for the interface, please click **System > Language** on the menu bar to select a desired language. Please note that if you want to change the language option, a message will remind you to restart the system.



*If you want to use "User Defined" language, please prepare images and language strings, and upload the files to the following folders:*

...|ST7501\Client\Playback\language\zz\_UD (language string)  
 ...|ST7501\Client\Playback\image (images)

## Query Panel-- Browsing Page



Icon	Description
	Station list including server and local database
	A station (a computer that has installed ST7501 Server)
	The camera that exists on the device tree of LiveClient.
	The camera that has been removed from the device tree of LiveClient (off-line). However, its recorded video (if any) is still accessible from the server.
	Dates with recorded video clips.
	Local database for backup data. For more information about how to upload backup data to the list, please refer to page 142.



## Query Panel--Time Search Page

Browsing Time Search Event Search Log Viewer

VVTK\_Station1(127.0.0.1)

- Cameras
  - 1\_PZ7131
  - 2\_IP8161
  - 3\_FD8161

Time Zone: GMT+08:00 Beijing, Chongqing, Hong k

☒ Start Time:

2009/11/23 08:50:15

☐ End Time:

2009/11/26 09:50:15

Search

Select station/ device(s) that you want to search for recorded files

Specify search period of time

Click to start to search, the results will be shown on the video clips list



The **Time Zone** is the same as your local computer.

## Query Panel--Event Search Page

**Event Search Page Interface Elements:**

- Tabs:** Browsing, Time Search, **Event Search**, Log Viewer
- Station Selection:**
  - ☒ VVTK\_Station1(127.0.0.1)
    - ☒ Cameras
      - ☒ 1\_PZ7131
      - ☒ 2\_IP8161
      - ☒ 3\_FD8161
- Search Categories:** All Events (dropdown)
- Search Criteria List:**
  - Motion - Window 1
  - Motion - Window 2
  - Motion - Window 3
  - IVA - Moving Object
  - IVA - Loitering Detection
  - IVA - Camera Tampering
  - IVA - Others
- Buttons:** Add, Remove
- Time Zone:** GMT+08:00 Beijing, Chongqing, Hong k (dropdown)
- Start Time:**
  - ☒ Start Time:
  - 2009/11/23 (date dropdown) 08:50:15 (time spinner)
- End Time:**
  - ☐ End Time:
  - 2009/11/26 (date dropdown) 09:50:15 (time spinner)
- Display Options:**
  - ☐ Display in New Result List
- Search Button:** Search

**Annotations:**

- Select station/ device(s) that you want to search for recorded files
- Select an Event Category
- Click to add search criteria
- Click to remove search criteria
- Specify search period of time
- Click to start to search, the results will be shown on the video clips list

## Query Panel--Log Viewer Page

The screenshot shows the 'Log Viewer' tab selected in the top navigation bar. Below the tabs is a list box containing 'VVTK\_Station1(127.0.0.1)'. To the right of this list box is a callout: 'Select station(s) that you want to search for recorded logs'. Below the list box are five dropdown menus: 'Category:' (set to 'All Local Logs'), 'User:', 'Result:' (set to 'All'), 'Log Type:' (set to 'All'), and 'Log Level:' (set to 'All'). To the right of each dropdown is a callout: 'Select a Log Category', 'Select a User Account', 'Select a Result Type', 'Select a Log Type', and 'Select a Log Level'. Below these dropdowns is a checkbox labeled 'Including above level' which is checked. Below this is a 'Time Zone:' dropdown set to 'GMT+08:00 Beijing, Chongqing, Hong k'. Below the time zone are two time selection sections. The first is 'Start Time:' with a checked checkbox, a date dropdown set to '2009/11/26', and a time spinner set to '08:50:16'. The second is 'End Time:' with an unchecked checkbox, a date dropdown set to '2009/11/26', and a time spinner set to '09:50:16'. To the right of both time sections is a callout: 'Specify search period of time'. At the bottom right is a 'Search' button. To its right is a callout: 'Click to start to search, the results will be listed on the video clips list'.

Browsing Time Search Event Search **Log Viewer**

VVTK\_Station1(127.0.0.1)

Category: All Local Logs

User:

Result: All

Log Type: All

Log Level: All

☒ Including above level

Time Zone: GMT+08:00 Beijing, Chongqing, Hong k

☒ Start Time:

2009/11/26 08:50:16

☐ End Time:

2009/11/26 09:50:16

Search

Select station(s) that you want to search for recorded logs

Select a Log Category

Select a User Account

Select a Result Type

Select a Log Type

Select a Log Level

Specify search period of time

Click to start to search, the results will be listed on the video clips list

## Video Clips List Window


If you select a **option “date”**, the video clips will be displayed in the video clips list window. A option “date” may contain more than one video clip.

The screenshot displays the VIVOTEK Playback software interface. On the left, the 'Browsing' pane shows a tree structure under 'Managed Stations' for 'VVTk\_Station1(127.0.0.1)'. Under 'Cameras', a 'Network Camera' is selected, and a date '2011-05-24' is highlighted with a yellow box and a hand cursor. The main area shows four camera feeds, all displaying the VIVOTEK logo. Below the feeds is a timeline with a blue bar representing a video clip. At the bottom, a table lists the video clips.


Index	Camera	Start	End	Time Zone	Description
1	Network Camera	2011-05-24 08:25:55	2011-05-24 18:55:04	+08:00	10 hours 29 mins 9 secs

## Playback Control Panel

When you double-click a video clip to play, the playback control panel will be enabled for you to use.



Icon	Function	Description
	Histogram Zoom In	Zoom in on the displayed period of time of the histogram
	Histogram Zoom Out	Zoom out of the displayed period of time of the histogram
	Marker I	If you want to export part of the recorded video clip, click to set marker I on the histogram, which will be the start time of the exported media
	Marker II	If you want to export part of the recorded video clip, click to set marker II on the histogram, which will be the end time of the exported media
	Export Media	Click to export the marked video clip
	Last Time Interval	Go to the previous video clip on the video clips list
	Pause	Pause playback the selected video clip
	Play	Start to playback the selected video clip
	Stop	Stop to playback the selected video clip
	Next Frame	Go to the next video frame of the selected video clip
	Next Time Interval	Go to the next video clip on the video clips list
	Repeat Mode	Playback the selected video clip repeatedly
	Slow Down	Slow down the playback rate
	Speed Up	Speed up the playback rate




The playing rate can be 1/8, 1/4, 1/2, 1X, 2X, 4X, 8X, 16X, 32X, and 64X.

## How to Playback Recorded Video


### Select a Recorded Video Clip

Please follow the steps below to select a video clip:

1. On the **Browsing** page, click the plus sign (+) to expand the device tree.




2. **Right-click** a station, device, or option "date" on the device tree and click **Refresh** to display the recorded video clips.




3. There are two ways to view the video clips of a date.

- View all video clips of a date:
  - a. Select a **option "date"** from the device tree.
  - b. **Double-click** the **option "date"** or **right-click** the **option "date"** and click **play**, and it will start to play in an available video cell. (You can also directly **drag-and-drop** the **option "date"** to a desired video cell in the recorded video playback window. The video clip will start to play.)



- View only one of the video clips of a date:
  - a. Click a **option** “date” on the device tree. The corresponding recorded video clips will be listed in the video clip list window.
  - b. Select a video clip from the video clip list window.
  - c. **Double-click** the video clip, then it will start to play in an available video cell. (You can also directly **drag-and-drop** the video clip to a desired video cell in the recorded video playback window. The video clip will start to play.)




4. Then you can make use of the playback control panel to playback the selected video clip. Please refer to **Playback Control Panel** on page 131.




## Remove Recorded Video Clips from Video Cells

There are two ways to remove a recorded video clip from the video cell:

1. **Right-click** the video cell and select **Remove**.



2. **Drag-and-drop** the live view from the video cell to the device tree window.



If you want to remove all live videos from the video cells, please click  on the menu bar.




## Timeline Slider Bar and Histogram

The red part of the histogram shows the period of time of a video clip. The timeline slider bar will move forward as the video is on playback. You can manually move forward/backward the **Timeline Slider Bar** to the desired position as shown below.


Start time of the histogram

End time of the histogram





The current time of the video clip will be displayed on the status panel. It will change according to the current position of the timeline slider bar.


## Zoom in / out of the Histogram



As the second picture shows, by clicking **Histogram Zoom In**, the total time of the histogram will shorten to half of the original period of time, while the red part of the histogram that shows the period of time of the video clip will extend to twice the original time span.

In addition to clicking  and  to zoom in/ out of the histogram, you can use the mouse directly to drag the histogram to zoom in part of the focused video clip. For example:

a. Drag a section of the histogram. You can drag it to either direction.



b. The section will be extended as shown below.



For more functions of the playback control buttons, please refer to page 131 for detailed description. |



## Audio Control



The audio function will be enabled if the device is equipped with an internal or external microphone. Please follow the steps below to adjust the volume or turn on/off the audio of the focused video:

### ■ To turn off the audio (Mute Mode)

- Click **Audio On** on the quick access bar and check **Mute**. Or you can **right-click** on the video cell to open the popup menu, then click **Others > Mute**. The mute option in the popup menu will then be selected.
- If you want to turn off the audio of all live video, select **Apply all**.
- The Audio icon will then change from to .





### ■ To adjust the audio volume

- Click **Audio On** on the quick access bar.
- Drag-and-drop the slider bar. Slide to a higher position for louder volume.

### ■ To turn on the audio

- Click **Mute** on the quick access bar and uncheck **Mute**. Or you can **right-click** on the video cell to open the popup menu, then click **Others > Mute**. The mute option in the popup menu will then be unchecked.
- If you want to turn on the audio of all live video, select **Apply all**.
- The Audio icon will then change from to .



## How to Change the Playback Layout

### Changing the Layout of the Recorded Video Playback Window


VIVOTEK ST7501 Playback supports up to 16-CH simultaneous recorded video playback on a single monitor and allows you to change the layout of the recorded live video playback window based on the number of inserted devices.

#### Switch Video Channels


**Drag-and-drop** a video channel to another empty video window.










To switch two channels, **drag-and-drop** one view to the other, then the two channels will switch positions.



#### Configure Layout Mode

Click the **Layout** button  on the quick access bar or click **Layout > Change Layout** on the menu bar. Select a desired layout mode and the layout window will change accordingly. Below we illustrate 6 types of layout modes:





Layout mode	Description
1 x 1	
2 x 2	
1 + 5	
3 x 3	
1 + 12	
4 x 4	



## Maximize/Minimize the Recorded Video Playback Window


- Single View: to maximize a video cell to the entire video playback window


**Double-click** the video cell, or **right-click** the video cell and select **Single View**. The focused video will occupy the entire Playback window as shown below.



To restore to the original layout, **double-click** the video cell or **right-click** the video cell and uncheck **Single View**.

- **Full Screen:** to maximize the video playback window to the entire screen

Click **Full Screen**  on the quick access bar or **right-click** the video cell and select **Full Screen**. In addition, you can also click **View > Full Screen** on the menu bar to maximize the recorded video playback window.





To restore to the original layout, **right-click** the video cell and uncheck **Full Screen**. You also can press the **Esc** button on the keyboard to leave the full screen mode.


- **Minimize:** If you click **View > Minimize** on the menu bar, the Playback window will minimize to the Windows tool bar.


## View Recorded Video with Multiple Monitors

If you have multiple screens in your control center, you can switch the ST7501 Playback Window among these screens.

- If you have two monitors, click **Switch Screen**  on the menu bar, the Playback window of monitor 1 will switch to monitor 2.



- If you have three or more monitors, a drop-down list will be displayed when you click **Switch Screen**  on the menu bar. The number of items on this list depends on the number of your screens. Select a desired screen from the drop-down list and the Playback Window will then switch to the specified screen.




## How to Backup Recorded Video


In addition to the Schedule Backup function of ST7501 LiveClient introduced on page 61, the ST7501 Playback also features to backup recorded video clips from the **local database**. Please open the **Browsing** page and follow the steps below to backup recorded video:

a. Select the target files.

- To backup all recorded video of a selected device: **Right-click** the device and click **Backup**.




- To backup all recorded video of the day: **Right-click** the option "date" and click **Backup** (or select the date and click the **Backup** button below).








- To backup part of the recorded video of the day: Select the date and choose the video clip(s) from video clip window. Then **right-click** the selected option(s) and click **Backup**. Note: Press **Shift** on your keyboard, then you can select more than one video clips.



- b. A **Backup Settings** window will pop up. Specify the time span and select a storage path, then click **Backup**. The system will start to backup and popup a window showing the backup status.



If you close the status window, you can also open it again by clicking **View > Backup Status**.



- d. When the backup is complete, you will see an information dialog. The recorded data will be restored in the specific folder.


## How to View Backup Files

The ST7501 Playback also allows users to playback backup files, including **Schedule Backup** by ST7501 LiveClient and **Recorded Data Backup** by ST7501 Playback.


Please follow the steps below to view backup files:

a. **Right-click** Local DB and click **Add**.

b. A **Load Backup File** window will pop up as shown below. Select the **\*.dif** file to upload.



c. The following is an example of uploaded file, and you can **double-click** it or **drag-and-drop** it to a video cell to playback.




## Model-specific Functions

The ST7501 Playback program offers model-specific functions through a right-click menu. For example, if you playback a video clip made from an FE8171V fisheye camera, a right-click on the playback screen will bring up the Display mode options. You can even exert mouse control while playing a recorded video. You can zoom in, zoom out, and change the view angle as if you are investigating a 3D scenario kept in a recorded point in time.


Note that ePTZ functions via the mouse control only takes place in a Regional view, e.g., the 1R or 1O3R mode.

The **Display mode** options and **mouse control** methodologies are identical to those described on page 34 and the following pages.



To configure the SVC-related feature:

1. Right-click on the playback window of an SVC-enabled camera. Select **SVC fps adjust bar**.



2. A slide bar will appear above the view cell. Click and drag the slide bar. A numeric indicator will display the current selection. See below for the frame rates represented by the numeric indicator. Please refer to page 24 for the introduction of this feature. Changing the SVC value takes immediate effect on the number of frames per second shown with the video being played.

Indicator	Frame rate per second (fps)
8	30
7	26
6	22
5	18
4	12
3	8
2	4
1	1
0	1/4



If you want to playback the backup files from the local database, you can also click **Working Offline** in the Login Window without the account information. The ST7501 Playback will launch as shown below.

ST7501 Playback

☐ Login local station

IP Address:

User Name:

Password:

Port:

Proxy Settings

**Working Offline** Login Cancel Hide <<

No user account information required

Playback

System Edit View Configuration Layout Help

User Name:  
Station Name:  
Login Time: 2009-11-27 15:46:42  
Current Time: 2009-11-27 15:47:25

Browsing

Managed Stations

Local DB

D:\NAS\1\_P27131\_20091125\_1254

1\_P27131

2009-11-25

You can upload backup files

VIVOTEK VIVOTEK VIVOTEK VIVOTEK

0000-00-00 00:00:00 0000-00-00 00:00:00


Index	Camera	Start	End	Time Zone	Description
1	1_P27131	2009-11-25 12:54:54	2009-11-25 13:02:09	+08:00	7 mins 14 secs



## How to Search for a Video Clip in a Specific Period of time


Please follow the steps below to use **Time Search** function:

a. Open the **Time Search** page.



b. Select the target station(s)/device(s) that you want to search for video clips.

c. Specify the time span. You can choose to set up the start time only, the end time only, or both the start time and end time. The search results will only include the video clips within the time span. If you uncheck both the start time and end time, the search results will include all video clips recorded by the selected device(s).



d. Click **Search** to start time search.


e. View the retrieved video clips.

## How to Search for Events

The ST7501 Playback program offers users an intuitive event search engine for retrieving video clips from the database of recorded videos based on different search criteria such as motion, IVA, or DI events.

Please follow the steps below to search for recorded events:

- a. Open the **Event Search** page.



repeat mode

- b. Select the target station(s)/device(s) that you want to search for events.
- c. Specify the **Event Category**. For detailed information, please refer to **Select Event Category** on the next page.
- d. Specify the time span for event search. You can choose to set up the start time only, the end time only, or both the start time and end time. The search results will only include the events within the time span. If you uncheck both the start time and end time, the search results will include all events from the selected device(s). Please refer to step c. on the previous page for detailed information.
- e. Start event search. Please refer to page 151 for detailed information.
- f. View the retrieved video clips. **Double-click** it or **drag-and-drop** it to the video cell. It will playback in repeat mode.

Note: The length of each video clip will depend on your settings of pre-event time & post-event time for the recording storage. The default setting is **20 seconds**. For more information, please refer to page 64 for detailed illustration.




## Select Event Category

The following introduces the event search categories: **All Events**, **All Motion Events**, **All IVA events**, **All DI Events**, **Named DI Events**, **PIR**, **Tampering**, and **Tamperature**. You can also add or remove customized events from the list.


### Event Category- All Events

If you select the **All Events** category, all of the events including motion detection, digital input, and intelligent video analysis, PIR, tamper detection, and tamperature alarm will be listed in the search results. You can click **Add** or **Remove** to change the search criteria options.



### Event Category- All Motion Events

If you select the **All Motion Events** category, all detected motion events will be included in the search. You can click **Add** or **Remove** to change the search criteria options.



The parameters of the motion detection windows, such as motion percentage and the time of occurrence are also recorded in the database of the server. If you want to change the parameters of the motion detection windows such as the position, size, detection sensibility, and motion percentage, please link to the camera's Configuration page to modify the values.

☒ Enable motion detection




## Event Category- All IVA events

If you select the **All IVA events** category, all detected IVA events will be included in the search. Cameras with embedded intelligent video content analysis are capable of detecting IVA events such as moving objects, loitering, and tamper detection.


The embedded video content analysis, superior to the conventional motion detection function, is capable of distinguishing between creature's motions and still backgrounds or natural movements such as swaying trees, waves or sunsets so as to prevent false alarms from environmental noise.

With camera tamper detection, it can detect incidents such as camera redirection, blocking or defocusing of cameras, or even spray-paint. Additionally, a suspicious object in the predefined detection region will trigger alarms once the dwell time of the object is longer than the given time.

You can click **Add** or **Remove** to change the search criteria items.




If you want to change the parameters of IVA, such as the detection region, loitering duration, etc, please link to the camera's Configuration page to modify the values.



## Event Category- All DI Events

If you select **All DI Events** category, all triggered DI signals will be included in the search. The DI events signify that there is a Digital-Input signal detected by the camera; its corresponding information such as DI-Trigger or DI-Normal signal and the time of occurrence are also transmitted and recorded in the database of the server.

You can click **Add** or **Remove** to change the search criteria options.




For more information about DI/DO settings on the connected devices, please refer to page 52 for detailed illustration.


## Event Category- Named DI Events

This category allows you to select only **Named DI Events**--the DI device which you have renamed in the LiveClient. Please refer to Association Management on page 52 for more information about how to rename DI device.

Click **OK** and fill in the name you want to search on the left window.



The new search criteria will be displayed in the search categories column as shown below. You can click **Add** or **Remove** to change the search criteria options.



## Start Event Search

After you specify all of the search criteria mentioned above, check/uncheck **Display in new result list** and click **Search** to begin event search.

- If **Display in new result list** is unchecked, all search results will be displayed on the original event list window as shown below.

Search Categories: All Motion Events

Motion - Window 1  
Motion - Window 2  
Motion - Window 3

Add Remove

Time Zone: GMT+08:00 Beijing, Chongqing, Ho

☒ Start Time: 2009/11/30 09:26:43

☐ End Time: 2009/11/30 10:26:43

☐ Display in New Result List Search

Index	Camera	Time	Time Zone	Type	Description
1	2_IP8161	2009-11-30 09:48:12	+08:00	Motion - Window 1	6%
2	2_IP8161	2009-11-30 09:48:23	+08:00	Motion - Window 1	10%
3	2_IP8161	2009-11-30 09:48:42	+08:00	Motion - Window 1	5%
4	2_IP8161	2009-11-30 09:48:50	+08:00	Motion - Window 1	5%
5	2_IP8161	2009-11-30 09:49:28	+08:00	Motion - Window 1	9%
6	2_IP8161	2009-11-30 09:49:51	+08:00	Motion - Window 1	5%
7	2_IP8161	2009-11-30 09:50:10	+08:00	Motion - Window 1	6%

Page 1

Unchecked

Only one page

- In the above picture, The **Type** field in the search result page shows the event category, and the **Description** field displays the motion **percentage** of the detection window. Please refer to page 148 for more information about Motion Events.

- If you select **Display in new result list** and click **Search**, the search results will be displayed on a new page as shown below. This allows you to place the search results of each search category on an individual page. You can set up to 5 pages in the event list window.

Search Categories: All Events

DI - Trigger  
DI - Normal  
PIR  
Tampering  
Temperature - Trigger  
Temperature - Normal

Add Remove

Time Zone: GMT+08:00 Beijing, Chongqing, Ho

☒ Start Time: 2009/11/30 09:26:43

☐ End Time: 2009/11/30 10:26:43

☒ Display in New Result List Search

Index	Camera	Time	Time Zone	Type	Description
1	3_FD8161	2009-11-30 09:44:54	+08:00	PIR	Trigger
2	3_FD8161	2009-11-30 09:44:54	+08:00	PIR	Trigger
3	3_FD8161	2009-11-30 09:44:55	+08:00	PIR	Trigger
4	3_FD8161	2009-11-30 09:44:55	+08:00	PIR	Trigger
5	3_FD8161	2009-11-30 09:44:56	+08:00	PIR	Trigger
6	3_FD8161	2009-11-30 09:44:56	+08:00	PIR	Trigger

Page 2 Page 1


Checked

You can set up to 5 pages.

## Backup the Event Videos

Please follow the steps below to backup the event videos on the results list:

- a. Select the video clips you want to backup. You can select more than one video clips.
- b. **Right-click** the selected video clips and click **Backup**.



Index	Camera	Time	Time Zone	Type	Description
1	3_FD8161	2009-11-30 09:44:54	+08:00	PIR	Trigger
2	3_FD8161	2009-11-30 09:44:54	+08:00	PIR	Trigger
3	3_FD8161	2009-11-30 09:44:55	+08:00	PIR	Trigger
4	3_FD8161	2009-11-30 09:44:55	+08:00	PIR	Trigger
5	3_FD8161	2009-11-30 09:44:56	+08:00	PIR	Trigger
6	3_FD8161	2009-11-30 09:44:56	+08:00	PIR	Trigger

Clear All Results  
 Backup  
 Show Milliseconds

Page 2    Page 1


- c. A **Backup Settings** window will pop up. For more information about how to set up the Backup Settings, please refer to page 140. For more information about how to view backup files, please refer to page 142 for detailed illustration.

## How to Search Logs

The ST7501 Playback program offers a convenient log engine for searching all local logs based on different search criteria such as log category, log type, and log level. The search results will be displayed in the log viewer window along with the detailed log history.

Please follow the steps below to search logs:

- Open the **Log Viewer** page.
- Select the target station where you want to search logs.
- Specify the **Log Category**. For detailed information, please refer to **Select Log Category** on page 154.
- Specify the **User Account**. If you have added other user accounts to the station, you can select one to search its login history. For detailed information about user account, please refer to **How to Manage User Accounts** on page 47.
- Specify the **Search Result**. Select **All** to display all search results; select **Success** to display successful log activities only; select **Fail** to display failed log activities only.
- Specify the **Log Type**. For detailed information, please refer to **Select Log Type** on page 154.
- Specify the **Log Level**. For detailed information, please refer to **Select Log Level** on page 154.
- Specify the search time span. You can check the start time only, the end time only, or both the start time and end time. The search will only include the events within the time span. If you uncheck both the start time and end time, the search will include all events saved by the server. Please refer to page 146 for detailed information.
- Start the log search and the results will be displayed on the log list window.





## Select Log Category/Log Type/Log Level

The following table shows the breakdown of log category, level, and type. The search results will be different according to your selections.

Log Categories	Log Levels	Log Types
Operation Log	Normal	Login / Logout
		Insert User
		Update User Name
		Update User Password
		Update User Privilege
		Delete User
		Insert Camera
		Update Camera Information
		Delete Camera
		Set Recording Group
		Insert Recording Schedule / Update Recording Schedule / Delete Recording Schedule
		Insert Event Management / Update Event Management / Delete Event Management
		Insert Recording Group / Update Recording Group / Delete Recording Group
		Insert Recording Path / Update Recording Path / Delete Recording Path
		Insert Camera to the Recording Group
		Update Camera information in the Recording Group
		Delete Camera from the Recording Group
		Move Recording Path
		Move Camera to another Recording Group
		Insert Layout / Update Layout / Delete Layout
		Set Digital Output
		Update Scheduled Backup
		Update Server Port
		Set Proxy Server
		Set UPNP
		Set DDNS Server
		Create Directory / Rename Directory / Delete Directory
		Insert SMTP Server / Update SMTP Server / Delete SMTP Server
		Insert Network Storage Device / Update Network Storage Device / Delete Network Storage Device
		Set GSM Modem
		Set DI/DO Rename
		Set Relay Settings
	High	Manually Begin Recording Manually Stop Recording
	Low	Camera PTZ, Iris, Focus, Pan, Patrol Control Click on Image Select Preset Location
System Log	High	Server Start / Server Stop Virtual Memory Low Network Lost
Event Log	High	Camera Disconnected from the Server / Camera Connected to the Server Parent Station Connection Lost / Parent Station Connection Restore Camera Recording Start / Camera Recording Stop Start Scheduled Backup / Stop Scheduled Backup Event Trigger



## Search All Local Logs

Log Category  
Log Level  
Log Type

Index	Time	Time Zone	Category	Level	Type	Result	User	Target	Description
1	2010-03-02 13:22:56	+08:00	Operation Log	Normal	Delete Camera	Success	STAdmin	Local	Target Camera Name=1_IP8161
2	2010-03-02 13:23:03	+08:00	Event Log	High	Camera Connected to ...	Success		Local	Target Camera Name=1_IP8161
3	2010-03-02 13:23:04	+08:00	Operation Log	Normal	Insert Camera	Success	STAdmin	Local	New Camera Name=1_IP8161, ...
4	2010-03-02 13:23:04	+08:00	Event Log	High	Camera Recording Stop	Success		Local	Target Camera Name=1_IP8161
5	2010-03-02 13:23:26	+08:00	Operation Log	High	Manually Begin Recording	Fail	STAdmin	Local	Target Camera Name=1_IP8161
6	2010-03-02 13:23:32	+08:00	Operation Log	High	Manually Begin Recording	Fail	STAdmin	Local	Target Camera Name=1_IP8161
7	2010-03-02 13:23:45	+08:00	Event Log	High	Camera Disconnected f...	Success		Local	Target Camera Name=1_IP8161
8	2010-03-02 13:23:52	+08:00	Operation Log	Normal	Delete Camera	Success	STAdmin	Local	Target Camera Name=1_IP8161
9	2010-03-02 13:24:07	+08:00	Operation Log	Normal	Insert Camera	Fail	STAdmin	Local	New Camera Name=1_FD8161,...
10	2010-03-02 13:24:23	+08:00	Operation Log	Normal	Insert Camera	Success	STAdmin	Local	New Camera Name=1_IP7161, ...
11	2010-03-02 13:24:24	+08:00	Event Log	High	Camera Recording Stop	Success		Local	Target Camera Name=1_IP7161
12	2010-03-02 13:24:24	+08:00	Event Log	High	Camera Connected to ...	Success		Local	Target Camera Name=1_IP7161
13	2010-03-02 13:24:25	+08:00	Event Log	High	Camera Recording Start	Success		Local	Target Camera Name=1_IP716...
14	2010-03-02 13:24:36	+08:00	Operation Log	High	Manually Begin Recording	Success	STAdmin	Local	Target Camera Name=1_IP7161
15	2010-03-02 13:24:37	+08:00	Event Log	High	Camera Recording Start	Success		Local	Target Camera Name=1_IP716...

Click to export all search results from the list

Click to remove all search results from the list

## Search Login History

Select **Login History** from the log category field and click the **Search** button below, the search results, including all login logs, will be displayed on the Login History page.

Browsing Time Search Event Search Log Viewer

VVTK\_Station1(192.168.5.122)

Category: Login History

User:

Result: All

Log Type: All

Log Level: All

☐ Include Login Time

Time Zone: GMT+08:00 Beijing, Chongqing, Hong Kong

☒ Start Time: 2010/ 2/ 1 08:31:21

☒ End Time: 2010/ 2/ 2 09:31:21

Index	User	Login Time	Login Result	Logout Time	Logout Result	Time Zone	Description
1	STAdmin	2010-02-01 09:41:38	Success	2010-02-01 11:48:52	Success	+08:00	Playback
2	STAdmin	2010-02-01 11:05:53	Success	2010-02-01 20:16:21	Success	+08:00	LiveClient
3	STAdmin	2010-02-01 11:48:55	Success	2010-02-01 20:16:15	Success	+08:00	Playback
4	STAdmin	2010-02-02 09:31:04	Success			+08:00	LiveClient

## Search Login Activities

This function allows you to search the operations the user performed during the login period of time. You can search for login activities on the Local Logs or Login History page.

### ■ Search Login Activities on the Local Logs page:

- Click on the **Local Logs** page.
- Select a login/logout option from the list.
- Click **Trace Login Activities** (or you can **right-click** the selected login/logout option on the list, then click **Trace Login Activities**).

Index	Time	Time Zone	Category	Level	Type	Result	User	Target	Description
1	2010-01-18 10:56:05	+08:00	System Log	High	Server Start	Success		Local	Service Name=VAST Recording ...
2	2010-01-18 10:56:05	+08:00	System Log	High	Server Start	Success		Local	Service Name=VAST Query Ser...
3	2010-01-18 10:56:16	+08:00	System Log	High	Server Start	Success		Local	Service Name=VAST Backup Se...
4	2010-01-18 10:56:18	+08:00	System Log	High	Server Start	Success		Local	Service Name=VAST Event Ser...
5	2010-01-18 10:56:21	+08:00	System Log	High	Server Start	Success		Local	Service Name=VAST Configurati...
6	2010-01-18 11:26:30	+08:00	Operation Log	Normal	Login	Success	STAdmin	Local	(LiveClient) User Account=STA...
7	2010-01-18 13:11:22	+08:00	Operation Log	Normal	Login	Success	STAdmin	Local	(Playback) User Account=STAd...
8	2010-01-18 16:14:24	+08:00	Event Log	High	Camera	Success		Local	Target Camera Name=1_IP8330
9	2010-01-18 16:14:25	+08:00	Operation Log	Normal	Insert	Success	STAdmin	Local	New Camera Name=1_IP8330, ...
10	2010-01-18 16:14:25	+08:00	Event Log	High	Camera	Success		Local	Target Camera Name=1_IP8330
11	2010-01-18 16:14:27	+08:00	Event Log	High	Camera	Success		Local	Target Camera Name=1_IP8330
12	2010-01-18 19:58:22	+08:00	Operation Log	Normal	Logout	Success	STAdmin	Local	(Playback) User Account=STAd...
13	2010-01-18 19:58:41	+08:00	Operation Log	Normal	Update Layout	Success	STAdmin	Local	Target LMS Name=Default Map...
14	2010-01-18 19:58:41	+08:00	Operation Log	Normal	Logout	Success	STAdmin	Local	(LiveClient) User Account=STA...
15	2010-01-18 19:59:12	+08:00	Operation Log	Normal	Login	Success	STAdmin	Local	(LiveClient) User Account=STA...
16	2010-01-18 20:07:24	+08:00	Operation Log	Normal	Logout	Success	STAdmin	Local	(LiveClient) User Account=STA...
17	2010-01-19 09:33:42	+08:00	System Log	High	Server Start	Success		Local	Service Name=VAST Query Ser...

Buttons: Clear All Results, Trace Login Activities, Export All Logs. Tabs: Local Logs, Login History, Login Activities.

d. The search results of the login activities will be displayed on the Login Activities page as shown below.

Index	Time	Time Zone	Category	Level	Type	Result	User	Target	Description
1	2010-01-18 11:26:30	+08:00	Operation Log	Normal	Login	Success	STAdmin	Local	(LiveClient) User Account=STA...
2	2010-01-18 16:14:25	+08:00	Operation Log	Normal	Insert Camera	Success	STAdmin	Local	New Camera Name=1_IP8330, ...
3	2010-01-18 19:58:41	+08:00	Operation Log	Normal	Update Layout	Success	STAdmin	Local	Target LMS Name=Default Map...
4	2010-01-18 19:58:41	+08:00	Operation Log	Normal	Logout	Success	STAdmin	Local	(LiveClient) User Account=STA...

Buttons: Clear All Results, Trace Login Activities, Export All Logs. Tabs: Local Logs, Login History, Login Activities.

### ■ Search Login Activities on the Login History page:

- Click on the **Login History** page.
- Select a login/logout option from the list.
- Click **Trace Login Activities** (or you can **right-click** the selected login/logout item on the list and click **Trace Login Activities**).

Index	User	Login Time	Login Result	Logout Time	Logout Result	Time Zone	Description
1	STAdmin	2010-02-01 09:41:38	Success	2010-02-01 11:48:52	Success	+08:00	Playback
2	STAdmin	2010-02-01 11:05:53	Success	2010-02-01 11:16:21	Success	+08:00	LiveClient
3	STAdmin	2010-02-01 11:48:55	Success		Success	+08:00	Playback
4	STAdmin	2010-02-02 09:31:04	Success		Success	+08:00	LiveClient

Buttons: Clear All Results, Trace Login Activities, Export All Logs. Tabs: Local Logs, Login History, Login Activities.

Buttons: Clear All Results, Trace Login Activities, Export All Logs. Tabs: Local Logs, Login History, Login Activities.

d. The search results of the login activities will be displayed on the Login Activities page as shown below.

Index	Time	Time Zone	Category	Level	Type	Result	User	Target	Description
1	2010-02-01 11:05:53	+08:00	Operation Log	Normal	Login	Success	STAdmin	Local	(LiveClient) User Account=STA...
2	2010-02-01 20:16:21	+08:00	Operation Log	Normal	Logout	Success	STAdmin	Local	(LiveClient) User Account=STA...



When you select **All** in the **Log Level** field, the search results will include all log levels. If you select **Low** in the **Log Level** field and select **Including above level** as shown in the picture on the left below, the search results will include all levels of logs. But if you select **Normal** in the **Log Level** field and select **Including above level** as shown in the picture on the right below, the search results will only include **Normal-level** and **High-level** logs.

Log Level:


☒ Including above level

Log Level:

☒ Including above level

## How to Configure Client Settings

On Client Settings, you can configure Snapshot Settings, Export Settings, View Settings, Proxy Settings, and General Settings. It allows you to save snapshots and media files on the local computer.



### Snapshot Settings



When you play a recorded video, ST7501 Playback also allows you to take snapshots. For detailed information about **Snapshot Settings**, please refer to page 103.


### Export Settings


When you playback a recorded video, the ST7501 server allows you to export part of the recorded video in EXE, 3GP, or AVI format to your local computer. Before exporting a media file, please set up Export Settings first. For detailed information about how to set up EXE, 3GP, and AVI **Export Settings**, please refer to Record Settings on page 105.



## Export an EXE/3GP/AVI File

Please follow the steps below to convert part of an EXE/3GP/AVI file of recorded video:

- Playback a video clip from which you want to export a media file.
- Set a period of time. Move the timeline slider bar to the desired start time and click Marker I . Move the timeline slider bar to the desired end time and click Marker II .



- Click Export EXE/3GP/AVI , the server will start to export the data and popup a window showing the exporting status. If you close the status window, you can also open it again by clicking **View > Exporting Status**.
- When the backup is complete, you will see an information dialog. The exported data will be restored in the preset storage folder on your local computer (C:\Program Files\VIVOTEK Inc\ST7501\Client\Playback\Export).



## View Settings

This section allows you to set up the display mode of video cell. For detailed information about **View Settings**, please refer to page 111.

## Proxy Settings

Please refer to page 119 for detailed illustration.


## General Settings

### System Settings

- Retrieve RTSP streaming on specific port: The default port for RTSP streaming is 554. If you want to change this port, please check this item and enter a desired port.

### Display Settings

- Enable de-interlace function: Select this option if your connected device does not support de-interlace function. For example: VS7100.



## How to Search for a Device on the Device Tree





The Playback also allows allows you to conveniently search for an inserted device. Please refer to page 120 for detailed information.



## How to Print a Video Image

The Playback also allows you print out an image of live video. Please refer to page 121 for detailed information.


## How to Lock ST7501 Playback for Security Concerns




If you happen to be away from your computer, for security reasons, we suggest you lock the program. When ST7501 Playback is locked, the user must enter the correct password to unlock and access the program again.

- To lock Playback, click **Unlock**  on the quick access bar or click **System > Lock** on the system menu. The **Unlock**  icon will then turn into **Lock** .
- To unlock Playback, click  and enter the correct password in the popup window.






## How to Log out from the ST7501 Server

To log out from the current server, click the station and click **Logout**  on the quick access bar or click **System > Logout** on the menu bar. You can also **right-click** the station and click **Logout**. A confirmation window will pop up. Click **OK** to confirm or **Cancel** to return to the ST7501 Playback window.



## How to Exit ST7501 Playback

To exit ST7501 Playback, click **Exit**  on the quick access bar or click **System > Exit** on the menu bar. A confirmation window will pop up. Click **OK** to confirm or **Cancel** to return to the ST7501 Playback window. When you exit the program, your user account will be automatically logged out from the current server.





# Import and Export Utility

ST7501 supports import and export utility for user to keep record of all server settings. You can use the export file to copy the configuration on another host.


## Export Utility

Please follow the steps below to export the server settings:

- a. Under Microsoft Windows, choose **"Start > All Programs > VIVOTEK Inc > ST7501 > Tools > Import-export Utility."**



- b. The **Import/Export Utility** window will pop up. Click **Export** and select a target folder. The system will start to export a .bin file.





## Import Utility

Please follow the steps below to import the server settings:

- a. Under Microsoft Windows, choose **"Start > All Programs > VIVOTEK Inc > ST7501 > Tools > Import-export Utility."**

- b. The **Import/Export Utility** window will pop up. Click **Import** and select the export file. The system will start to import the file.





# ST7501 Service Control Tool

ST7501 service control tool is a tool for server control and for user to be aware of the ST7501 Server status. It starts up as Windows OS startup.


Under Microsoft Windows, choose "**Start > All Programs > VIVOTEK Inc > ST7501 > Tools > VNSServiceControl.**"



You may also find it in the system tray icon of the tool bar, which indicates that the service is running: 

It shows a disconnection icon when the service is stopped: 

A menu for the service control tool will pop up when you **right-click** on the icon:



Here you can manually start, stop and restart the service.